Original		Sustituto	
STANDBY/ON	Standby/On		Power
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
TV STANDBY/ON	Tv Standby/On	SHIFT +	Shift + Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7 TV/DVD	Tv/DVD	MEDIA DISPLAY	Display / Media
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
9 INPUT SEL	Input Sel	RDS AV INPUT	AV / Input / RDS
0	0	HDMI-BAT 0	0
⏮	I<<	PRESET- ⏮	I<< / Preset-
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ

Original		Sustituto	
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
⏭	>>I	PRESET+ ⏭	>>I / Preset+
⏪	<<	TUNE- ⏪	<< / Tune-
STOP	Stop	HOLD ■	Stop / Hold
PLAY ⏯	PLay/Pause	SLOW ▶	Play / Slow
⏩	>>	TUNE+ ⏩	>> / Tune+
TV VOL +	Tv Vol +	+ VOL	Vol +
TV MUTE AUDIO	Mute	DIMMER MUTE	Mute / Dimmer
PROG ▲	PR+	+ CH PAGE	CH+ / Page+
TV VOL −	Tv Vol -	VOL −	Vol -
PROG ▼	PR-	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
RETURN	Return	RETURN BACK	Back / Return
▲	Up	▲	Up
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right

Original	Sustituto	Original	Sustituto
Down	Down		
Title List/Disc Menu	D.Menu / Top		
Info	Info / Angle		
Exit	Exit / Cancel / Clear		
Play List/Title Menu	Smart / List		
Red/A	Red / Netflix / Search		
Green/B	Green / APP / Repeat		
Yellow/C	Yellow / YouTube / Repeat		
Blue/D	Blue / Prime Video / Random		
Copy	Picture / Format		
Marker	Fav / Marker / PC		
Rec Mode	Shift + Rec / Rec Mode		
Timer	Sleep / Timer		
Rec	Rec / Rec Mode		
Pause/Rec Pause/Time Shift	Pause / Step / Freeze		