Mandis shop

Sony RM-SC3

Original		Sustituto	
I / ⏻	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
DISPLAY	Display	DISPLAY INFO	Info
CLOCK/TIMER SELECT	Clock Timer	TIMER AV	AV
CLOCK/TIMER SET	Clock Timer SET	ECO 3D	3D
TUNER MEMORY	Tuner Memory	1	1
PLAY MODE/ TUNING MODE	Play Mode/ Tuning Mode	2	2
PLAY MODE/ TUNING MODE	Play Mode/ Tuning Mode	SHIFT + PLAY MODE ▶	Shift + Play
REPEAT/ FM MODE	Repeat / FM	3	3
REPEAT/ FM MODE	Repeat / FM	REPEAT TEXT	Text
TAPE	Tape	A	Red
CD	CD	B	Green
TUNER BAND	Band/ Tuner	C	Yellow
FUNCTION	Function	HOME SMART	Smart
−	I <<I / -		I <<
+	>>I / +		>>I
	<<		<<

Original		Sustituto	
	>>		>>
	Play	PLAY MODE ▶	Play
	Pause		Pause
	Stop		Stop
CLEAR	Clear	CLEAR EXIT	Exit
EQ	EQ	APP MEDIA	Media
ENTER	Enter	OK	Ok
DISC SKIP	Disk Skip	DISC NAV LIST	List
VOLUME	Vol +	VOL +	Vol +
VOLUME	Vol -	VOL −	Vol -
− ALBUM	Album-	CH −	Ch -
+ ALBUM	Album+	CH +	Ch +

https://mandis.es/es/Sony/1859-600-mando-sustituto-para-Sony-RM-SC3-14582.html