Original	Sustituto	Original	Sustituto
Power Source	Shift + Power	Audio 2	Shift + 2
Power Receiver	Power	Tuner	Shift + 6
HDMI 1	Red / Netflix / Search	USB	Shift + 8
HDMI 2	Green / APP / Repeat	Net	Shift + 4
HDMI 3	Yellow / YouTube / Repeat	Phono	Shift + 3
HDMI 4	Blue / Prime Video / Random	Party	TV/Radio /
HDMI 5	Shift + 5	HDMI Out	AV / Input / RDS
HDMI 6	Shift + 0	BD/DVD Scene	Shift + Up
HDMI 7	Shift + 9	TV Scene	Shift + Left
V-AUX	Shift + 7	NET Scene	Shift + Right
AV 1	Shift + Red / Netflix /	Radio Scene	Shift + Down
AV 2	Shift + Green / APP /	Program Up	CH+ / Page+
AV 3	Shift + Yellow / YouTube /	Volume+	Vol +
AV 4	Shift + Blue / Prime	Program Down	CH- / Page-
AV 5	Shift + Guide / EPG / -/--	Mute	Mute / Dimmer
AV 6	Shift + Fav / Marker / PC	Volume-	Vol -
Audio 1	Shift + 1	Top Menu	D.Menu / Top Menu

Original		Sustituto	
POP-UP/MENU	Pop-Up Menu	HOME MENU	Menu / Home
ON SCREEN	On Screen	GOTO TEXT	Text / Goto
	Up		Up
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MODE	Mode	LIST SMART	Smart / List
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
BAND	Play/Band	SLOW	Play / Slow
	<< Tuning	TUNE-	<< / Tune-
	Tuning >>	TUNE+	>> / Tune+
	I<< Preset	PRESET-	I<< / Preset-

Original		Sustituto	
	Preset >>I	PRESET+	>>I / Preset+
MOVIE	Movie	TITLE SOUND	Sound / Title
MUSIC	Music	LANG I/II AUDIO	Audio / Lang I/II
SUR. DECODE	Sur. Decode	SURROUND	Eject / Surround
STRAIGHT	Straight	FORMAT PICTURE	Picture / Format
INFO	Info	ANGLE INFO	Info / Angle
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ENHANCER	Enhancer	EQ SUBTITLE	Subtitle / EQ
PURE DIRECT	Pure Direct	SIZE ZOOM	Zoom / Size
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8

Original		Sustituto		Original	Sustituto
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
MEMORY +10	+10/Memory	-/-- GUIDE EPG	Guide / EPG / -/--		
ENT	ENT.	PC FAV MARKER	Fav / Marker / PC		

Original		Sustituto	
	Power Source	SHIFT +	Shift + Power
	Power Receiver		Power
1	HDMI 1	NETFLIX SEARCH	Red / Netflix / Search
2	HDMI 2	APP REPEAT	Green / APP / Repeat
3	HDMI 3	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	HDMI 4	Prime Video RANDOM	Blue / Prime Video / Random
5	HDMI 5	SHIFT + TAPE 5	Shift + 5
6	HDMI 6	SHIFT + HDMI - SAT 0	Shift + 0
7	HDMI 7	SHIFT + BLUETOOTH 9	Shift + 9
V-AUX	V-AUX	SHIFT + AUX - HDD 7	Shift + 7
1	AV 1	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
2	AV 2	SHIFT + APP REPEAT	Shift + Green / APP /
3	AV 3	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
4	AV 4	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
5	AV 5	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
6	AV 6	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
1	Audio 1	SHIFT + TV 1	Shift + 1

Original		Sustituto	
2	Audio 2	SHIFT + DVD 2	Shift + 2
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
USB	USB	SHIFT + USB 8	Shift + 8
NET	NET	SHIFT + VIDEO 4	Shift + 4
PHONO	Phono	SHIFT + CD - STB 3	Shift + 3
PARTY	Party	PROGRAM TV/RADIO	TV/Radio /
HDMI OUT	HDMI Out	RDS AV INPUT	AV / Input / RDS
BD DVD	BD/DVD Scene	SHIFT +	Shift + Up
TV	TV Scene	SHIFT +	Shift + Left
NET	NET Scene	SHIFT +	Shift + Right
RADIO	Radio Scene	SHIFT +	Shift + Down
VOLUME +	Volume+	VOL +	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME -	Volume-	VOL -	Vol -
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
POP-UP/MENU	Pop-Up Menu	HOME MENU	Menu / Home
ON SCREEN	On Screen	GOTO TEXT	Text / Goto

Original		Sustituto	
	Up		Up
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
MODE	Mode	LIST SMART	Smart / List
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
BAND	Play/Band	SLOW	Play / Slow
	<< Tuning	TUNE-	<< / Tune-
	Tuning >>	TUNE+	>> / Tune+
	I<< Preset	PRESET-	I<< / Preset-
	Preset >>I	PRESET+	>>I / Preset+
INFO	Info	ANGLE INFO	Info / Angle

Original		Sustituto	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
MEMORY +10	+10/Memory	-/-- GUIDE EPG	Guide / EPG / -/--
ENT	ENT	PC FAV MARKER	Fav / Marker / PC