Original	Rechange	Original	Rechange
Power	Power	P+	CH+ / Page+
1	1	P+	Up
2	2	-	Left
3	3	-	Vol -
PIP	Smart / List	OK	OK
4	4	+	Right
5	5	+	Vol +
6	6	TXT	Text / Goto
[<>]	Picture / Format	P-	CH- / Page-
7	7	P-	Down
8	8	AV	AV / Input / RDS
9	9	Scan/[ ]	Setup / OPT /
-/--	Guide / EPG / -/--	PAP/Pause	Display / Media
0	0	Size/Stop	Zoom / Size
Mute	Mute / Dimmer	Pos/Play	D.Menu / Top
i	Info / Angle	Red/I<	Red / Netflix / Search
Z	Menu / Home	Green/>I	Green / APP / Repeat

Original	Rechange	Original	Rechange
Yellow/Pause/ <	Yellow / YouTube / Repeat		
Blue/ >>	Blue / Prime Video / Random		

Original		Rechange		Original		Rechange	
	Power		Power	P+	P+		Up
1	1	TV 1	1		-		Left
2	2	DVD 2	2		-	VOL	Vol -
3	3	CD - STB 3	3	OK	OK	OK	OK
PIP	PIP	LIST SMART	Smart / List		+		Right
4	4	VIDEO 4	4		+	+ VOL	Vol +
5	5	TAPE 5	5	TXT	TXT	GOTO TEXT	Text / Goto
6	6	TUNER 6	6	P-	P-	CH PAGE	CH- / Page-
	[<>]	FORMAT PICTURE	Picture / Format	P-	P-		Down
7	7	AUX - HDD 7	7	AV	AV	RDS AV INPUT	AV / Input / RDS
8	8	USB 8	8	SCAN	Scan/[']	OPT-TOOLS SETUP	Setup / OPT /
9	9	BLUETOOTH 9	9	PAP	PAP/Pause	STEP - FREEZE	Pause / Step / Freeze
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--	SIZE	Size/Stop	HOLD	Stop / Hold
0	0	HDMI - SAT 0	0	POS	Pos/Play	SLOW	Play / Slow
i	i	ANGLE INFO	Info / Angle		Red/I<	PRESET-	I<< / Preset-
Z	Z	HOME MENU	Menu / Home		Green/>I	PRESET+	>>I / Preset+
P+	P+	+ CH PAGE	CH+ / Page+		Yellow/Pause/<	TUNE-	<< / Tune-

Original	Rechange	Original	Rechange
Bl ue/ >>	>> / Tune+		

Original		Rechange		Original		Rechange	
	Power		Power		P+		CH+ / Page+
1	1	1	1		P+		Up
2	2	2	2		-		Left
3	3	3	3		-	VOL	Vol -
PIP	PIP	SMART	Smart / List	OK	OK	OK	OK
4	4	4	4		+	VOL	Vol +
5	5	5	5		+		Right
6	6	6	6	TXT	TXT	GOTO TEXT	Text / Goto
	[<>]	FORMAT PICTURE	Picture / Format		P-	CH PAGE	CH- / Page-
7	7	7	7		P-		Down
8	8	8	8	AV	AV	RDS AV INPUT	AV / Input / RDS
9	9	9	9		Scan/[ ]	OPT-TOOLS SETUP	Setup / OPT /
-/--	-/--	GUIDE EPG	Guide / EPG / -/--		PAP/Pause	STEP-FREEZE	Pause / Step / Freeze
0	0	0	0		Size/Stop	HOLD	Stop / Hold
	Mute	DIMMER MUTE	Mute / Dimmer		Pos/Play	SLOW	Play / Slow
i	i	ANGLE INFO	Info / Angle		Red/I<	PRESET-	I<< / Preset-
Z	Z	HOME MENU	Menu / Home		Green/>I	PRESET+	>>I / Preset+

Original		Rechange		Original		Rechange	
	Yel l ow/ <<		<< / Tune-				
	Bl ue/ >>		>> / Tune+				

Original		Rechange	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
PIP	PIP	SMART	Smart / List
4	4	4	4
5	5	5	5
6	6	6	6
[<>]	[<>]	PICTURE	Picture / Format
7	7	7	7
8	8	8	8
9	9	9	9
-/--	-/--	GUIDE EPG	Guide / EPG / -/--
0	0	0	0
i	i	INFO	Info / Angle
Z	Z	MENU	Menu / Home
P+	P+	CH	CH+ / Page+

Original		Rechange	
P+	P+		Up
	-	VOL -	Vol -
	-		Left
OK	OK	OK	OK
	+	VOL +	Vol +
	+		Right
TXT	TXT	TEXT	Text / Goto
P-	P-	CH PAGE -	CH- / Page-
P-	P-		Down
AV	AV	AV INPUT	AV / Input / RDS
SCAN	Scan/[']]	SETUP	Setup / OPT /
PAP	PAP/Pause	STEP-FREEZE	Pause / Step / Freeze
SIZE	Size/Stop	STOP	Stop / Hold
POS	Pos/Play	PLAY	Play / Slow
	Red/I<	PRESET-	I<< / Preset-
	Green/>I	PRESET+	>>I / Preset+
	Yellow/Pause/<	TUNE-	<< / Tune-

Original	Rechange	Original	Rechange
Bl ue/ >>	>> / Tune+		