Original	Rechange	Original	Rechange
CD	SHIFT + 3 (CD - STB) Shift + 3	TV	GUIDE EPG Guide / EPG / -/--
TAPE	SHIFT + 5 (TAPE) Shift + 5	1	1 (TV) 1
VCR	SHIFT + 4 (VIDEO) Shift + 4	2	2 (DVD) 2
TUNER	SHIFT + 6 (TUNER) Shift + 6	3	3 (CD - STB) 3
TXT	GOTO TEXT Text / Goto	4	4 (VIDEO) 4
DCC	SHIFT + 2 (DVD) Shift + 2	5	5 (TAPE) 5
DSR	SHIFT + 7 (AUX - HDD) Shift + 7	6	6 (TUNER) 6
DIG. REC	SHIFT + 8 (USB) Shift + 8	7	7 (AUX - HDD) 7
TV	SHIFT + 1 (TV) Shift + 1	8	8 (USB) 8
A SPEAKERS	LIST SMART Smart / List	9	9 (BLUETOOTH) 9
SPEAKERS B	MEDIA DISPLAY Display / Media	0	0 (HDMI - SAT) 0
VOLUME AUDIO +	+ VOL Vol +	MUTE	DIMMER MUTE Mute / Dimmer
VOLUME AUDIO -	VOL - Vol -	PRESET TRACK	PRESET+ >>I / Preset+
VOLUME TV -	Left	PRESET TRACK	PRESET- I<< / Preset-
VOLUME TV +	Right	STANDBY	Power
AUDIO PROC -	Down	HOLD STOP	HOLD Stop / Hold
PROCESSOR +	Up	MEMO OUT PLAY	REC MODE Rec / Rec Mode

Out

Original		Rechange	
REVEAL	TV-TXT Reveal	SLOW	Play / Slow
CANCEL PAUSE	TV-TXT Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TIME	TV-TXT Time	TIMER SLEEP	Sleep / Timer
ENLARGE MODE	TXT Enlarge	SIZE ZOOM	Zoom / Size
ENLARGE MODE	TV Mode	OK	OK
PRESET TRACK	TXT Preset +	CH PAGE +	CH+ / Page+
PRESET TRACK	TXT Preset -	CH PAGE -	CH- / Page-
STANDBY	DCC Standby	SHIFT +	Shift + Power
MUTE	DCC Mute	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
DECK A DISC	DCC Disc +	SHIFT + CH PAGE +	Shift + CH+ /
DISC DECK B	DCC Disc -	SHIFT + CH PAGE -	Shift + CH- /
PRESET TRACK	DCC Track +	SHIFT + PRESET+	Shift + >>I / Preset+
PRESET TRACK	DCC Track -	SHIFT + PRESET-	Shift + I<< / Preset-
HOLD STOP	DCC Stop	SHIFT + HOLD	Shift + Stop /
MEMO OUT PLAY	DCC Play	SHIFT + SLOW	Shift + Play /
REVEAL	DCC <<	SHIFT + TUNE-	Shift + << /
CANCEL PAUSE	DCC Pause	SHIFT + STEP-FREEZE	Shift + Pause / Step / Freeze

Original		Rechange	
TIME	DCC >>	SHIFT + TUNE+	Shift + >> /
ENLARGE MODE	DCC Mode	SHIFT + OK	Shift + OK
OPEN/CLOSE	DCC	SHIFT + SURROUND	Shift + Eject / Surround

Original		Rechange	
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
CD	CD	SHIFT + CD-STB 3	Shift + 3
TXT	TXT	GOTO TEXT	Text / Goto
TV	TV	SHIFT + TV 1	Shift + 1
DSR	DSR	SHIFT + AUX-HDD 7	Shift + 7
DCC	DCC	SHIFT + DVD 2	Shift + 2
DIG. REC	DIG. REC	SHIFT + USB 8	Shift + 8
A SPEAKERS	Speakers A	LIST SMART	Smart / List
SPEAKERS B	Speakers B	MEDIA DISPLAY	Display / Media
VOLUME AUDIO +	Volume Audio +	+ VOL	Vol +
VOLUME AUDIO -	Volume Audio -	VOL -	Vol -
PROCESSOR +	Audio Processor	▲	Up
AUDIO PROC -	Audio Processor	▼	Down
VOLUME TV +	Volume TV +	▶	Right
VOLUME TV -	Volume TV -	◀	Left

Original		Rechange	
STANDBY	CD Standby	⏻	Power
1	CD 1	TV 1	1
2	CD 2	DVD 2	2
3	CD 3	CD-STB 3	3
4	CD 4	VIDEO 4	4
5	CD 5	TAPE 5	5
6	CD 6	TUNER 6	6
7	CD 7	AUX-HDD 7	7
8	CD 8	USB 8	8
9	CD 9	BLUETOOTH 9	9
0	CD 0	HDMI-SAT 0	0
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
DECK A DISC	CD Disc +	+ CH PAGE	CH+ / Page+
DISC DECK B	CD Disc -	CH PAGE -	CH- / Page-
PRESET TRACK	CD Track +	PRESET+ ▶▶	>>I / Preset+
PRESET TRACK	CD Track -	PRESET- ◀◀	I<< / Preset-
HOLD STOP	CD Stop	HOLD ■	Stop / Hold

Original		Rechange	
MEMO OUT / PLAY	CD Play	SLOW	Play / Slow
REVEAL	CD <<	TUNE-	<< / Tune-
CANCEL / PAUSE	CD Pause	STEP-FREEZE	Pause / Step / Freeze
TIME	CD >>	TUNE+	>> / Tune+
ENLARGE / MODE	CD Mode	OK	OK
OPEN/CLOSE	CD Open/Close	SURROUND	Eject / Surround
STANDBY	DSR Standby	SHIFT +	Shift + Power
DECK A / DISC	DSR Disc +	SHIFT + CH PAGE +	Shift + CH+ /
DISC / DECK B	DSR Disc -	SHIFT + CH PAGE -	Shift + CH- /
PRESET TRACK	DSR Preset/Track	SHIFT + PRESET+	Shift + >>I / Preset+
PRESET TRACK	DSR Preset/Track	SHIFT + PRESET-	Shift + I<< / Preset-
ENLARGE / MODE	DSR Mode	SHIFT + OK	Shift + OK

Original	Rechange

Original		Rechange	
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
CD	CD	SHIFT + CD-STB 3	Shift + 3
TV	TV	SHIFT + TV 1	Shift + 1
DCC	DCC	SHIFT + DVD 2	Shift + 2
DSR	DSR	SHIFT + AUX-HDD 7	Shift + 7
DIG. REC	DIG. REC	SHIFT + USB 8	Shift + 8
TXT	TXT	GOTO TEXT	Text / Goto
A SPEAKERS	Speakers A	LIST SMART	Smart / List
SPEAKERS B	Speakers B	MEDIA DISPLAY	Display / Media
VOLUME AUDIO +	Volume Audio +	+ VOL	Vol +
VOLUME AUDIO -	Volume Audio -	VOL −	Vol -
VOLUME TV -	Volume TV -	◀	Left
VOLUME TV +	Volume TV +	▶	Right
AUDIO PROC −	Audio Processor	▼	Down
PROCESSOR +	Audio Processor	▲	Up

Original		Rechange	
1	TUNER 1	TV 1	1
2	TUNER 2	DVD 2	2
3	TUNER 3	CD-STB 3	3
4	TUNER 4	VIDEO 4	4
5	TUNER 5	TAPE 5	5
6	TUNER 6	TUNER 6	6
7	TUNER 7	AUX-HDD 7	7
8	TUNER 8	USB 8	8
9	TUNER 9	BLUETOOTH 9	9
0	TUNER 0	HDMI-SAT 0	0
STANDBY	TUNER Standby	⏻	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PRESET TRACK	TUNER Preset +	PRESET+ ▶▶|	>>I / Preset+
PRESET TRACK	TUNER Preset -	PRESET- |◀◀	I<< / Preset-
REVEAL ◀◀	TUNER <<	TUNE- ◀◀	<< / Tune-
TIME ▶▶	TUNER >>	TUNE+ ▶▶	>> / Tune+
ENLARGE MODE	TUNER Mode	OK	OK

Original	Rechange	Original	Rechange
TAPE Standby	SHIFT + Power		
TAPE Preset +	SHIFT + PRESET+		
TAPE Deck A	SHIFT + LIST SMART		
TAPE Preset -	SHIFT + PRESET-		
TAPE Deck B	SHIFT + MEDIA DISPLAY		
TAPE Stop	SHIFT + HOLD		
TAPE Play	SHIFT + SLOW		
TAPE <<	SHIFT + TUNE-		
TAPE >>	SHIFT + TUNE+		
TAPE Mode	SHIFT + OK		
TAPE Record	SHIFT + REC MODE		
TAPE Pause	SHIFT + STEP-FREEZE		
TAPE	SHIFT + SURROUND		

Original		Rechange	
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TXT	TXT	GOTO TEXT	Text / Goto
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
CD	CD	SHIFT + CD-STB 3	Shift + 3
TV	TV	SHIFT + TV 1	Shift + 1
DCC	DCC	SHIFT + DVD 2	Shift + 2
DSR	DSR	SHIFT + AUX-HDD 7	Shift + 7
DIG. REC	DIG. REC	SHIFT + USB 8	Shift + 8
A SPEAKERS	Speakers A	LIST SMART	Smart / List
SPEAKERS B	Speakers B	MEDIA DISPLAY	Display / Media
VOLUME AUDIO +	Volume Audio +	VOL +	Vol +
VOLUME AUDIO -	Volume Audio -	VOL -	Vol -
VOLUME TV -	Volume TV -		Left
VOLUME TV +	Volume TV +		Right
AUDIO PROC -	Audio Processor		Down
PROCESSOR +	Audio Processor		Up

Original		Rechange	
1	VCR 1	TV 1	1
2	VCR 2	DVD 2	2
3	VCR 3	CD-STB 3	3
4	VCR 4	VIDEO 4	4
5	VCR 5	TAPE 5	5
6	VCR 6	TUNER 6	6
STANDBY	VCR Standby		Power
7	VCR 7	AUX-HDD 7	7
8	VCR 8	USB 8	8
9	VCR 9	BLUETOOTH 9	9
0	VCR 0	HDMI-SAT 0	0
VCR	VCR -/--	-/-- GUIDE EPG	Guide / EPG / -/--
MUTE	VCR Mute	DIMMER MUTE	Mute / Dimmer
PRESET TRACK	VCR Preset/Track	PRESET+	>>I / Preset+
PRESET TRACK	VCR Preset/Track	PRESET-	I<< / Preset-
HOLD STOP	VCR Stop	HOLD	Stop / Hold
MEMO OUT PLAY	VCR Play	SLOW	Play / Slow

Original	Rechange	Original	Rechange
VCR <<	<< / Tune-		
VCR Pause	Pause / Step / Freeze		
VCR >>	>> / Tune+		
VCR Record	Rec / Rec Mode		
VCR Mode	OK		
VCR Open/Close	Eject / Surround		
DIG.REC	Shift + Power		
DIG.REC Mute	Shift + Mute / Dimmer		
DIG.REC Preset/Track +	Shift + >>I / Preset+		
DIG.REC Preset/Track -	Shift + I<< / Preset-		
DIG.REC Stop	Shift + Stop /		
DIG.REC Pause	Shift + Pause / Step /		
DIG.REC <<	Shift + << /		
DIG.REC >>	Shift + >> /		
DIG.REC Mode	Shift + OK		
DIG.REC Play	Shift + Play /		
DIG.REC Open/Close	Shift + Eject / Surround		