Original	Rechange	Original	Rechange
Power MD	Power	Right	Right
TV	TV/R	Left	Left
CD	Yellow	Enter	Ok
DVD	Blue	Menu	D. Menu
Tuner/Band	Green	Display	Info
Tape	Red	Top Menu/Disc/Deck	Menu
VCR	Smart	1 MD	1
MD	Media	2 MD	2
Vol +	Vol +	3 MD	3
Vol -	Vol -	4 MD	4
Muting	Mute	5 MD	5
Stop MD	Stop	6 MD	6
Play MD	Play	7 MD	7
<</I<< MD	<<	8 MD	8
>>/>>I MD	>>	9 MD	9
Up	Up	0 MD	0
Down	Down	>10/-/-- MD	Guide

Original		Rechange	
TV/AV	Tv/AV	TIMER AV	AV
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH -	Ch -
Power TV		SHIFT + Power	Shift + Power
TV VOL ^	Tv Vol Up	SHIFT + VOL +	Shift + Vol +
TV VOL v	Tv Vol Down	SHIFT + VOL -	Shift + Vol -
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5

Original		Rechange	
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
0	0 Tv	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/-- Tv	SHIFT + -/-- GUIDE	Shift + Guide

Original		Rechange	
	Power DVD		Power
	TV		TV/R
	VCR		Smart
	Tuner/Band		Green
	Tape		Red
	MD		Media
	CD		Yellow
	DVD		Blue
	Play DVD		Play
	I<</<< DVD		<<
	Stop DVD		Stop
	>>/>>I DVD		>>
	Top Menu/Disc/Deck		Menu
	Display		Info
	Menu		D. Menu
	Up		Up
	Down		Down

Original		Rechange	
	Right		Right
	Left		Left
	Enter		Ok
	Stereo		Dual
	Surround		Options
	SFC		Subt
	Test		Back
	Delay		Format
	Level		3D
	+		Ch +
	-		Ch -
	1 DVD		1
	2 DVD		2
	3 DVD		3
	4 DVD		4
	5 DVD		5
	6 DVD		6

Original		Rechange	
7	7 DVD	7	7
8	8 DVD	8	8
9	9 DVD	9	9
0	0 DVD	0	0
≥10/-/--	>10/-/-- DVD	-/-- GUIDE	Guide
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
MUTING	Muting	MUTE	Mute

Original	Rechange

Original		Rechange	
	Power CD		Power
	TV		TV/R
	VCR		Smart
	CD		Yellow
	DVD		Blue
	Tape		Red
	MD		Media
	Tuner/Band		Green
	Stop CD		Stop
	I<</<< CD		<<
	>>/>>I CD		>>
	Play CD		Play
	Menu		D. Menu
	Display		Info
	Top Menu/Disc/Deck		Menu
	Up		Up
	Down		Down

Original		Rechange	
	Right		Right
	Left		Left
	Enter		Ok
	Stereo		Dual
	Surround		Options
	SFC		Subt
	Test		Back
	Delay		Format
	Level		3D
	+		Ch +
	-		Ch -
	Vol +		Vol +
	Vol -		Vol -
	Muting		Mute
	Power Tape		Shift + Power
	Stop Tape		Shift + Stop
	Play Tape		Shift + Play

Original		Rechange	
I <</ << Tape		SHIFT + <<	Shift + <<
>>/ >>I Tape		SHIFT + >>	Shift + >>
Top Menu/ Disc/ Deck		SHIFT + TOP MENU MENU	Shift + Menu
1 CD- Tape		1	1
2 CD- Tape		2	2
3 CD- Tape		3	3
4 CD- Tape		4	4
5 CD- Tape		5	5
6 CD- Tape		6	6
7 CD- Tape		7	7
8 CD- Tape		8	8
9 CD- Tape		9	9
0 CD- Tape		0	0
>10/ -/ -- CD- Tape		-/-- GUIDE	Guide
Direct Tuning/ Disc Ente		REPEAT TEXT	Text

Original	Rechange

Original		Rechange	
	Power VCR		Power
	VCR	HOME SMART	Smart
	Tape	A	Red
	TV	SEARCH TV/R	TV/R
	CD	C	Yellow
	DVD	D	Blue
TUNER/ BAND	Tuner/Band	B	Green
	MD	APP MEDIA	Media
	Stop		Stop
	I<</<<	<<	<<
	>>/>>I	>>	>>
	Play	PLAY MODE	Play
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4
5	5 VCR	5	5

Original		Rechange	
6	6 VCR	6	6
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
≥10/-/--	>10/--/-- VCR	-/-- GUIDE	Guide
DIRECT TUNING/ DISC ENTER	Direct Tuning/Disc Ente	REPEAT TEXT	Text
VOL +	Vol +	+ VOL	Vol +
− VOL	Vol -	VOL −	Vol -
MUTING	Muting	MUTE	Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TOP MENU DISC/DECK 1/2	Top Menu/Disc/Deck	TOP MENU MENU	Menu
DISPLAY	Display	DISPLAY INFO	Info

Original		Rechange	
MENU	Menu	E-MANUAL D.MENU	D. Menu
STEREO	Stereo	SOUND DUAL	Dual
SURROUND	Surround	SETTINGS OPT	Options
SFC	SFC	AD SUBT	Subt
TEST	Test	RETURN BACK	Back
DELAY	Delay	PICTURE FORMAT	Format
LEVEL	Level	ECO 3D	3D
+	+	+ CH	Ch +
-	-	CH -	Ch -
Power	Power Tuner / Band	SHIFT + Power	Shift + Power
1	1 Tuner / Band	SHIFT + 1	Shift + 1
2	2 Tuner / Band	SHIFT + 2	Shift + 2
3	3 Tuner / Band	SHIFT + 3	Shift + 3
4	4 Tuner / Band	SHIFT + 4	Shift + 4
5	5 Tuner / Band	SHIFT + 5	Shift + 5
6	6 Tuner / Band	SHIFT + 6	Shift + 6
7	7 Tuner / Band	SHIFT + 7	Shift + 7

Original		Rechange	
8	8 Tuner / Band	SHIFT + 8	Shift + 8
9	9 Tuner / Band	SHIFT + 9	Shift + 9
0	0 Tuner / Band	SHIFT + 0	Shift + 0
≥10/-/--	>10/-/--	SHIFT + -/-- GUIDE	Shift + Guide