Original		Rechange		Original		Rechange	
ON	Power		Power				
PROGRAM +	Program+	CH +	Ch +				
PROGRAM -	Program-	CH -	Ch -				
REC	Rec	REC MODE	Rec				
PLAY	Play	PLAY MODE	Play				
FF	>>	>>	>>				
REW	<<	<<	<<				
STOP	Stop	■	Stop				
PAUSE	Pause	❚❚	Pause				