Mandis shop

RM-D597

| Original | | Rechange | |
|---|---|---|---|
| A.SPACE/ A.CUE | A. Space/ A. Cue | RDS AV INPUT | AV / Input / RDS |
| MUSIC SCAN | Music Scan | TITLE SOUND | Sound / Title |
| CONTINUE | Play Mode | SIZE ZOOM | Zoom / Size |
| SHUFFLE | Play Mode Shuffl | FORMAT PICTURE | Picture / Format |
| PROGRAM | Play Mode | PROGRAM TV/ RADIO | TV/ Radio / |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 10 | 10 | HDMI - SAT 0 | 0 |
| >10 | >10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |

| Original | | Rechange | |
|---|---|---|---|
| TIME | Time | TIMER SLEEP | Sleep / Timer |
| REPEAT | Repeat | APP REPEAT | Green / APP / Repeat |
| FADER | Fader | DIMMER MUTE | Mute / Dimmer |
| | Play | SLOW | Play / Slow |
| | Pause | STEP - FREEZE | Pause / Step / Freeze |
| | Stop | HOLD | Stop / Hold |
| AMS | I<< | PRESET- | I<< / Preset- |
| AMS | >>I | PRESET+ | >>I / Preset+ |
| LINE OUT LEVEL + | Line Out Level + | VOL + | Vol + |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| LINE OUT LEVEL - | Line Out Level - | VOL - | Vol - |

https://mandis.co/fr/Sony-10245380-telecommande-remplacement-pour-Sony-RM-D597.html