Original		Rechange	
	Power Source	SHIFT +	Shift + Power
	Power Receiver		Power
1	HDMI 1	SHIFT + 1	Shift + 1
2	HDMI 2	SHIFT + 2	Shift + 2
3	HDMI 3	SHIFT + 3	Shift + 3
4	HDMI 4	SHIFT + 4	Shift + 4
1	AV 1	SHIFT + 6	Shift + 6
2	AV 2	SHIFT + 7	Shift + 7
3	AV 3	SHIFT + 9	Shift + 9
MHL 5	HDMI 5/MHL	SHIFT + 5	Shift + 5
4	AV 4	SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--
5	AV 5	SHIFT + 0	Shift + 0
6	AV 6	SHIFT + FAV MARKER	Shift + Fav / Marker / PC
★	*	PROGRAM TV/RADIO	TV/Radio /
V-AUX	V-AUX	RDS AV INPUT	AV / Input / RDS
USB	USB	SHIFT + 8	Shift + 8
NET	Net	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS

Original		Rechange	
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
FM	FM	LIST SMART	Smart / List
AM	AM	SHIFT + LIST SMART	Shift + Smart / List
PRESET	Presset Up	SHIFT + PRESET+	Shift + >>I / Preset+
PRESET	Presset Up	CH PAGE +	CH+ / Page+
TUNING	Tunning Up	SHIFT + TUNE+	Shift + >> /
INFO	Info	ANGLE INFO	Info / Angle
MEMORY	Memory	GOTO TEXT	Text / Goto
PRESET	Preset Down	SHIFT + PRESET-	Shift + I<< / Preset-
PRESET	Preset Down	CH PAGE -	CH- / Page-
TUNING	Tuning Down	SHIFT + TUNE-	Shift + << /
MOVIE	Movie	SHIFT +	Shift + Left
MUSIC	Music	SHIFT +	Shift + Up
SUR. DECODE	Sur. Decode	SHIFT + OK	Shift + OK
STRAIGHT	Straight	SHIFT +	Shift + Right
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ENHANCER	Enhancer	SHIFT +	Shift + Down

Original		Rechange	
DIRECT	Direct	SHIFT + ANGLE INFO	Shift + Info / Angle
BD DVD	Scene BD/DVD	NETFLIX SEARCH	Red / Netflix / Search
TV	Scene TV	APP REPEAT	Green / APP / Repeat
NET	Scene Net	YouTube REPEAT A-B	Yellow / YouTube / Repeat
RADIO	Scene Radio	Prime Video RANDOM	Blue / Prime Video / Random
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
▲	Up	▲	Up
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
VOLUME +	Vol +	VOL +	Vol +
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
VOLUME −	Vol -	VOL −	Vol -
RETURN	Return	RETURN BACK	Back / Return
▼	Down	▼	Down
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top Menu

Original		Rechange	
POP-UP MENU	Pop-Up Menu	HOME MENU	Menu / Home
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
MODE	Mode	REC MODE	Rec / Rec Mode
■	Stop	HOLD ■	Stop / Hold
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
▶	Play	SLOW ▶	Play / Slow
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
I◀◀	I<<	PRESET- I◀◀	I<< / Preset-
▶▶I	>>I	PRESET+ ▶▶I	>>I / Preset+
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7

Menu

Original		Rechange		Original	
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--		
ENT	ENT	PC FAV MARKER	Fav / Marker / PC		