Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
NICAM/A2	Nicam/A2	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
PMODE	P.Mode	FORMAT PICTURE	Picture / Format
SMODE	S.Mode	TITLE SOUND	Sound / Title
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
0	0	HDMI - SAT 0	0

Original		Replacement	
	Recall	RETURN BACK	Back / Return
DISPLAY	Display	MEDIA DISPLAY	Display / Media
FREEZE	Freeze	STEP - FREEZE	Pause / Step / Freeze
AUTO	Rec/Auto	REC MODE	Rec / Rec Mode
RED	Red	NETFLIX SEARCH	Red / Netflix / Search
GREEN	Green	APP REPEAT	Green / APP / Repeat
YELLOW	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
BLUE	Blue	Prime Video RANDOM	Blue / Prime Video / Random
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Up		Up
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Replacement	
CH	CH+	CH PAGE +	CH+ / Page+
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
VOL	Vol+	+ VOL	Vol+
CH	CH-	CH PAGE −	CH- / Page-
T.SHIFT	T.Shift	OPT-TOOLS SETUP	Setup / OPT /
VOL	Vol-	VOL −	Vol-
HOLD	Play/Pause/Hold	SLOW ▶	Play / Slow
HOLD	Play/Pause/Hold	SHIFT + HOLD ■	Shift + Stop /
REVEAL	<<</Reveal	TUNE- ◀◀	<< / Tune-
SIZE	>>/Size	SIZE ZOOM	Zoom / Size
SIZE	>>/Size	TUNE+ ▶▶	>> / Tune+
INDEX	Stop/Index	HOLD ■	Stop / Hold
I<<	I<<	PRESET- I◀◀	I<< / Preset-
S.PAGE	S.Page/>>I	PRESET+ ▶▶I	>>I / Preset+
TEXT	Text	GOTO TEXT	Text / Goto
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Replacement	
DTV	DTV	LIST SMART	Smart / List
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
TV/RADIO	Tv/Radio	PROGRAM TV/ RADIO	TV/Radio /