Mandis shop

TRAVELHD

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | >>I/Next | >>I |
| Home | Smart | Zoom | Eject |
| X | AV | Vol+ | Vol + |
| Menu | Menu | Vol- | Vol - |
| Edit | Exit | Mute | Mute |
| Up | Up | | |
| Down | Down | | |
| Right | Right | | |
| Left | Left | | |
| Enter | Ok | | |
| Info | Info | | |
| Play | Play | | |
| Pause | Pause | | |
| Stop | Stop | | |
| <</FR | << | | |
| >>/FF | >> | | |
| I<</Prev | I<< | | |

https://mandisremotes.com/en/WE/1058570-90734-replacement-remote-control-for-WE-Travel-HD-1T-Travel-HD.html