Original		Replacement	
STANDBY	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
PROGRAM	Program	PROG SLEEP	Sleep
RETURN TITLE	Title/Return	RETURN BACK	Back
SYSTEM MENU	Menu/System	TOP MENU MENU	Menu
DISC MENU	Menu/Disc	E-MANUAL D.MENU	D. Menu
OK	OK	OK	Ok
	Up		Up

Original		Replacement	
	Down		Down
	Right		Right
	Left		Left
	I<<		I<<
	>>I		>>I
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
TV VOL +	Tv Vol+	CH +	Ch +
TV VOL −	Tv Vol-	CH −	Ch -
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
SUBTITLE	Subtitle	AD SUBT	Subt
ANGLE	Angle	SETTINGS OPT	Options
ZOOM	Zoom	ZOOM	Eject
AUDIO	Audio	SOUND DUAL	Dual

Original		Replacement		Original	Replacement
REPEAT	Repeat	REPEAT TEXT	Text		
REPEAT A-B	A-B Repeat	A	Red		
BASS	Bass	HOME SMART	Smart		
TREBLE	Treble	APP MEDIA	Media		
SURR.	Surr.	TIMER AV	AV		
SOUND	Sound	SHIFT +	SOUND DUAL Shift + Dual		
NIGHT	Night	ECO 3D	3D		
CD UP SAMP	CD UP Samp.	C	Yellow		
DIM	DIM	FAV PRE-CH	Pre Ch		
DISPLAY	Display	DISPLAY INFO	Info		

Original		Replacement	
STANDBY	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
PROGRAM	Program	PROG SLEEP	Sleep
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
	I<<		I<<
	>>I		>>I
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
TV VOL +	Tv Vol+	CH +	Ch +
TV VOL −	Tv Vol-	CH −	Ch -
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
BASS	Bass	HOME SMART	Smart
TREBLE	Treble	APP MEDIA	Media
SURR.	Surr.	TIMER AV	AV
SOUND	Sound	SOUND DUAL	Dual
NIGHT	Night	ECO 3D	3D
DIM	DIM	FAV PRE-CH	Pre Ch
MUTE	Mute	MUTE	Mute

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Program		Sleep
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
	I<<		I<<
	>>I		>>I
	Vol+		Vol +
	Vol-		Vol -
	Tv Vol+		Ch +
	Tv Vol-		Ch -
	Mute		Mute
	Bass		Smart
	Treble		Media
	Surr.		AV
	Sound		Dual
	Night		3D
	DIM		Pre Ch
	Play		Play
	Pause		Pause
	Stop		Stop