Original		Replacement	
POWER	Power		Power
TITLE	Title	SETTINGS OPT	Options
SUBTITLE	Subtitle	AD SUBT	Subt
Scr.SIZE	SCR Size	PICTURE FORMAT	Format
ANGLE	Angle	A	Red
REPEAT	Repeat	REPEAT TEXT	Text
A-B REPEAT	A-B Repeat	B	Green
Brt.CONT	BRT Cont.	D	Blue
DEVICE	Device	C	Yellow
MENU	Menu	TOP MENU MENU	Menu
SETUP	Setup	E-MANUAL D.MENU	D. Menu
INFO	Info	DISPLAY INFO	Info
SEARCH	Search	SEARCH TV/R	TV/R
AUDIO	Audio	SOUND DUAL	Dual
MOVIE	Movie	SHIFT + 1	Shift + 1
TV OUT	Tv Out	TIMER AV	AV
MUSIC	Music	SHIFT + 2	Shift + 2

Original		Replacement	
PHOTO	Photo	SHIFT + 3	Shift + 3
ALL MEDIA	All Media	SHIFT + 4	Shift + 4
SLOW	←Slow	RETURN BACK	Back
STOP	Stop		Stop
OK	Play	PLAY MODE	Play
OK	Pause		Pause
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
	>>		>>
	<<		<<
NEXT	>>I		>>I
PREV	I<<		I<<
SELECT 1	1/Select	1	1
SELECT ALL 2	2/Select All	2	2

Original		Replacement		Original	Replacement
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
REFRESH 8	8/Refresh	8	8		
9	9	9	9		
SLEEP 0	0/Sleep	0	0		
BOOKMARK ./	./ Bookmark	-/-- GUIDE	Guide		
MUTE	Mute	MUTE	Mute		
+ VOLUME	Vol+	+ VOL	Vol +		
VOLUME −	Vol-	VOL −	Vol -		