| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| TV/AV | Tv/AV | RDS AV INPUT | AV / Input / RDS |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| -/-- | -/-- | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| 0 | 0 | HDMI - SAT 0 | 0 |
| | Back | RETURN BACK | Back / Return |
| V+ | Vol+ | + VOL | Vol+ |
| SCAN | Scan | LIST SMART | Smart / List |
| P+ | P+ | + CH PAGE | CH+ / Page+ |

| Original | | Replacement | |
|---|---|---|---|
| V- | Vol- | VOL – | Vol- |
| ZOOM | Zoom | SIZE ZOOM | Zoom / Size |
| P- | P- | CH PAGE – | CH- / Page- |
| | Up | | Up |
| | Left | | Left |
| OK SELECT | OK/Select | OK | OK |
| | Right | | Right |
| MENU | Menu | HOME MENU | Menu / Home |
| | Down | | Down |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| | Red / Picture | NETFLIX SEARCH | Red / Netflix / Search |
| | Red / Picture | FORMAT PICTURE | Picture / Format |
| | Green / Sound | APP REPEAT | Green / APP / Repeat |
| | Green / Sound | TITLE SOUND | Sound / Title |
| SLEEP | Yellow / Sleep | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| SLEEP | Yellow / Sleep | TIMER SLEEP | Sleep / Timer |
| CALL | Blue / Call | Prime Video RANDOM | Blue / Prime Video / Random |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| TEXT | Text | GOTO TEXT | Text / Goto | | |
| MIX | Mix | SHIFT + GOTO TEXT | Shift + Text / | | |
| SIZE | Size | SHIFT + SIZE ZOOM | Shift + Zoom / | | |
| INDEX | Index | REC MODE | Rec / Rec Mode | | |
| HOLD | Hold | HOLD | Stop / Hold | | |
| REVEAL | Reveal | SLOW | Play / Slow | | |
| SUBPAGE | Subpage | EQ SUBTITLE | Subtitle / EQ | | |
| CANCEL | Cancel | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| DVB MENU | DVB Menu | TOP MENU D.MENU | D.Menu / Top | | |
| i | i | ANGLE INFO | Info / Angle | | |
| EPG | EPG | -/-- GUIDE EPG | Guide / EPG / -/-- | | |
| ESC | ESC | PC FAV MARKER | Fav / Marker / PC | | |
| DVB | DVB | MEDIA DISPLAY | Display / Media | | |
| FREEZE | Freeze | STEP - FREEZE | Pause / Step / Freeze | | |
| I/II | I/II | LANG I/II AUDIO | Audio / Lang I/II | | |
| | | | | | |
| | | | | | |