Original		Replacement	
Source	Source	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
Power	Power	Power	
List	List	LIST SMART	Smart / List
TV	TV	SHIFT + TV 1	Shift + 1
DVD	DVD	SHIFT + DVD 2	Shift + 2
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
AV	AV	RDS AV INPUT	AV / Input / RDS
0/--	0/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
FAV.	FAV	PC FAV MARKER	Fav / Marker / PC

Original		Replacement	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Menu	Menu	HOME MENU	Menu / Home
▲	Up	▲	Up
◀	Left / Zoom-	◀	Left
OK	OK	OK	OK
▶	Right / Zoom+	▶	Right
▼	Down	▼	Down
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
RETURN	Return	RETURN BACK	Back / Return
INFO	Info	ANGLE INFO	Info / Angle
+	Vol +	+ VOL	Vol +
PRESETS	Presets	OPT-TOOLS SETUP	Setup / OPT /
+ PR	PR+	+ CH PAGE	CH+ / Page+
−	Vol -	− VOL	Vol -
PR −	PR-	− CH PAGE	CH- / Page-
Mute	Mute	DIMMER MUTE	Mute / Dimmer
Lang	Red/ O) Lang	NETFLIX SEARCH	Red / Netflix / Search

Original		Replacement		Original	Replacement
	Red/O) Lang		Audio / Lang I/II		
	Green/Subtitle		Subtitle / EQ		
	Green/Subtitle		Green / APP / Repeat		
	Yellow		Yellow / YouTube / Repeat		
	Blue		Blue / Prime Video / Random		
	Violet/Text		Text / Goto		
	Stop Text	+	Shift + Stop /		
	??? Text		Sleep / Timer		
	Zoom Text		Zoom / Size		
	Media/Digital		Display / Media		
	<<		<< / Tune-		
	Play		Play / Slow		
	>>		>> / Tune+		
	T-Link		D.Menu / Top		
	Rec		Rec / Rec Mode		
	Stop		Stop / Hold		
	Pause		Pause / Step / Freeze		

Original		Replacement	
Power	Power	Power	
List	List	Smart / List	
TV	TV	Shift +	1
DVD	DVD	Shift +	2
1	1	1	
2	2	2	
3	3	3	
4	4	4	
5	5	5	
6	6	6	
7	7	7	
8	8	8	
9	9	9	
AV	AV	AV / Input / RDS	
0/--	0/--	Shift +	Guide / EPG / -/--
Exit	Exit	Exit / Cancel / Clear	
Menu	Menu	Menu / Home	

Original		Replacement	
Up	Up	Up	
Left / Zoom-	Left / Zoom-	Left	
OK	OK	OK	OK
Right / Zoom+	Right / Zoom+	Right	
Down	Down	Down	
Guide	Guide	Guide / EPG / -/--	
Return	Return	Back / Return	
Info	Info	Info / Angle	
Vol + Tv	Vol + Tv	Vol +	
Presets	Presets	Setup / OPT /	
PR+	PR+	CH+ / Page+	
Vol - Tv	Vol - Tv	Vol -	
PR-	PR-	CH- / Page-	
Mute	Mute Tv	Mute / Dimmer	
Lang	Red/O) Lang	Audio / Lang I/II	
Lang	Red/O) Lang	Red / Netflix / Search	
Subtitles	Subtitles	Subtitle / EQ	

Original		Replacement		Original	Replacement
Subtitles	Green/Subtitle	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
TEXT	Violet/Text	GOTO TEXT	Text / Goto		
	<<	TUNE-	<< / Tune-		
	Play	SLOW	Play / Slow		
	>>	TUNE+	>> / Tune+		
	Rec	REC MODE	Rec / Rec Mode		
	Stop	HOLD	Stop / Hold		
	Pause	STEP-FREEZE	Pause / Step / Freeze		

Original	Replacement	Original	Replacement
Source / Eject	Eject / Surround	Exit	Exit / Cancel / Clear
Power	Power	Menu	Menu / Home
List	Smart / List	Up	Up
TV	Shift + 1	Left	Left
DVD	Shift + 2	OK	OK
1	1	Right	Right
2	2	Down	Down
3	3	Guide	Guide / EPG / -/--
4	4	Return	Back / Return
5	5	Info	Info / Angle
6	6	Vol +	Vol +
7	7	PR +	CH+ / Page+
8	8	Vol -	Vol -
9	9	PR -	CH- / Page-
AV	AV / Input / RDS	Mute	Mute / Dimmer
0 / --	Shift + Guide / EPG / -/--	Red / A-B	Shift + Yellow / YouTube /
FAV	Fav / Marker / PC	Red / A-B	Red / Netflix / Search

Original		Replacement		Original	Replacement
Subtitles	Green / Subtitle	APP REPEAT	Green / APP / Repeat		
Subtitles	Green / Subtitle	EQ SUBTITLE	Subtitle / EQ		
	Yellow / Size	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Yellow / Size	SIZE ZOOM	Zoom / Size		
	Blue / Lang	Prime Video RANDOM	Blue / Prime Video / Random		
	Blue / Lang	LANG I/II AUDIO	Audio / Lang I/II		
TEXT	Purple / Text	GOTO TEXT	Text / Goto		
STOP	Text Stop	SHIFT + HOLD	Shift + Stop /		
???	Text ???	TIMER SLEEP	Sleep / Timer		
ZOOM	Text Zoom	SHIFT + SIZE ZOOM	Shift + Zoom /		
	<<	TUNE-	<< / Tune-		
	Play	SLOW	Play / Slow		
	>>	TUNE+	>> / Tune+		
	Stop	HOLD	Stop / Hold		
	Pause	STEP-FREEZE	Pause / Step / Freeze		