Original		Replacement	
Standby	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PIP-	PIP-	SHIFT + CH PAGE −	Shift + CH+ /
PIP	PIP	SIZE ZOOM	Zoom / Size
PIP+	PIP+	SHIFT + CH PAGE +	Shift + CH+ /
WIDE	Wide	FORMAT PICTURE	Picture / Format
SWAP	Swap	LIST SMART	Smart / List
LANG(AD)	Lang(AD)	LANG I/II AUDIO	Audio / Lang I/II
TIMERS	Timers	TIMER SLEEP	Sleep / Timer
1..?*	1	TV 1	1
2abc	2	DVD 2	2
3def	3	CD - STB 3	3
4ghi	4	VIDEO 4	4
5jkl	5	TAPE 5	5
6mno	6	TUNER 6	6
7pqrs	7	AUX - HDD 7	7
8tuv	8	USB 8	8

Original		Replacement	
9wxyz	9	BLUETOOTH 9	9
TEXT	Text	GOTO TEXT	Text / Goto
AV 0&@_	0	HDMI - SAT 0	0
AV 0&@_	AV	RDS AV INPUT	AV / Input / RDS
i	i	ANGLE INFO	Info / Angle
VOL+	Vol +	+ VOL	Vol +
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
P+	PR+	+ CH PAGE	CH+ / Page+
VOL-	Vol -	VOL −	Vol -
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
P-	PR-	CH PAGE −	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
▲	Up	▲	Up

Original		Replacement		Original	Replacement
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
◀	Left	◀	Left		
OK	OK	OK	OK		
▶	Right	▶	Right		
MENU	Menu	HOME MENU	Menu / Home		
▼	Down	▼	Down		
P<P BACK	Back/P<P	RETURN BACK	Back / Return		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
▶	Play	SLOW ▶	Play / Slow		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
LIB	LIB	OPT-TOOLS SETUP	Setup / OPT /		
■	Stop	HOLD ■	Stop / Hold		
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
●	Rec	REC MODE ●	Rec / Rec Mode		