Original	Replacement	Original	Replacement
Power	Power	P+	CH+ / Page+
1	1	P+	Up
2	2	-	Left
3	3	-	Vol -
PIP	Smart / List	OK	OK
4	4	+	Right
5	5	+	Vol +
6	6	TXT	Text / Goto
[<>]	Picture / Format	P-	CH- / Page-
7	7	P-	Down
8	8	AV	AV / Input / RDS
9	9	Scan/ [ ]	Setup / OPT /
-/--	Guide / EPG / -/--	PAP/ Pause	Display / Media
0	0	Size/ Stop	Zoom / Size
Mute	Mute / Dimmer	Pos/ Play	D. Menu / Top
i	Info / Angle	Red/ I <	Red / Netflix / Search
Z	Menu / Home	Green/ >I	Green / APP / Repeat

Original	Replacement	Original	Replacement
Yellow/ Pause/ <	Yellow / YouTube / Repeat		
Blue/ >>	Blue / Prime Video / Random		

Original		Replacement		Original		Replacement	
	Power		Power		P+		Up
1	1	1	1		-		Left
2	2	2	2		-	VOL	Vol -
3	3	3	3	OK	OK	OK	OK
PIP	PIP	SMART	Smart / List		+		Right
4	4	4	4		+	VOL	Vol +
5	5	5	5	TXT	TXT	TEXT	Text / Goto
6	6	6	6		P-	CH PAGE	CH- / Page-
	[<>]	PICTURE	Picture / Format		P-		Down
7	7	7	7	AV	AV	AV INPUT	AV / Input / RDS
8	8	8	8	SCAN	Scan/[']	SETUP	Setup / OPT /
9	9	9	9	PAP	PAP/Pause		Pause / Step / Freeze
-/--	-/--	GUIDE EPG	Guide / EPG / -/--	SIZE	Size/Stop	HOLD	Stop / Hold
0	0	0	0	POS	Pos/Play	SLOW	Play / Slow
i	i	INFO	Info / Angle		Red/I<	PRESET-	I<< / Preset-
Z	Z	MENU	Menu / Home		Green/>I	PRESET+	>>I / Preset+
P+	P+	CH PAGE	CH+ / Page+		Yellow/Pause/<	TUNE-	<< / Tune-

<

Original	Replacement	Original	Replacement
Bl ue/ >>	>> / Tune+		

Original	Replacement	Original	Replacement
Power	Power	P+	CH+ / Page+
1	1	P+	Up
2	2	-	Left
3	3	-	Vol -
PIP	Smart / List	OK	OK
4	4	+	Vol +
5	5	+	Right
6	6	TXT	Text / Goto
[<>]	Picture / Format	P-	CH- / Page-
7	7	P-	Down
8	8	AV	AV / Input / RDS
9	9	Scan/ [ ]	Setup / OPT /
-/--	Guide / EPG / -/--	PAP/ Pause	Pause / Step / Freeze
0	0	Size/ Stop	Stop / Hold
Mute	Mute / Dimmer	Pos/ Play	Play / Slow
i	Info / Angle	Red/ I <	I << / Preset-
Z	Menu / Home	Green/ >I	>>I / Preset+

Original	Replacement	Original	Replacement
Yel l ow/ <<	<< / Tune-		
Bl ue/ >>	>> / Tune+		

Original	Replacement	Original	Replacement
Power	Power	P+	Up
1	1	-	Vol -
2	2	-	Left
3	3	OK	OK
PIP	Smart / List	+	Vol +
4	4	+	Right
5	5	TXT	Text / Goto
6	6	P-	CH- / Page-
[<>]	Picture / Format	P-	Down
7	7	AV	AV / Input / RDS
8	8	Scan/[']	Setup / OPT /
9	9	PAP/ Pause	Pause / Step / Freeze
-/--	Guide / EPG / -/--	Size/ Stop	Stop / Hold
0	0	Pos/ Play	Play / Slow
i	Info / Angle	Red/ I <	I << / Preset-
Z	Menu / Home	Green/ >I	>>I / Preset+
P+	CH+ / Page+	Yellow/ Pause/ <	<< / Tune-

<

Original	Replacement	Original	Replacement
Bl ue/ >>	TUNE+ >> / Tune+		