Original	Replacement	Original	Replacement
Open/Close	Eject / Surround	Pop Up/Menu	Smart / List
Power	Power	<<	<< / Tune-
1	1	Play	Play / Slow
2	2	Pause	Pause / Step / Freeze
3	3	>>	>> / Tune+
4	4	I <<	I << / Preset-
5	5	Stop	Stop / Hold
6	6	>>I	>>I / Preset+
7	7	Home	Menu / Home
8	8	Setting	Setup / OPT /
9	9	Exit	Exit / Cancel / Clear
Goto	Text / Goto	Step/Slow	Shift + Play /
0	0	Step/Slow	Shift + Pause / Step /
Clear	Shift + Exit / Cancel / Clear	Up	Up
OSC	Sound / Title	Left	Left
Top Menu	D. Menu / Top	OK	OK
PIP	Picture / Format	Right	Right

Original	Replacement	Original	Replacement
Return	Back / Return		
Down	Down		
Red/ Program	Red / Netflix / Search		
Red/ Program	TV/ Radio /		
Green/ Digest	Green / APP / Repeat		
Yellow/ Zoom	Yellow / YouTube / Repeat		
Yellow/ Zoom	Zoom / Size		
Blue/ Bookmark	Blue / Prime Video / Random		
Sub	Subtitle / EQ		
Audio	Audio / Lang I/II		
2nd. Audio	Shift + Audio / Lang I/II		
Angle	Info / Angle		
A-B	Shift + Yellow / YouTube /		
Repeat	Shift + Green / APP /		
Display	Display / Media		