Original		Replacement	
STANDBY	Standby	SHIFT + POWER	Shift + Power
POWER	Power	POWER	Power
CD	CD	SHIFT + CD-STB 3	Shift + 3
MD/CD-R	MD/CD-R	SHIFT + TAPE 5	Shift + 5
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
★	*	SHIFT + BLUETOOTH 9	Shift + 9
DVD	DVD	SHIFT + DVD 2	Shift + 2
DTV/CBL	DTV/CBL	SHIFT + TV 1	Shift + 1
DVR	DVR	SHIFT + USB 8	Shift + 8
V-AUX	V-AUX	SHIFT + AUX-HDD 7	Shift + 7
MULTI CH IN	Multi CH In	SHIFT + VIDEO 4	Shift + 4
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
+ VOLUME	Vol +	+ VOL	Vol +
VOLUME −	Vol -	VOL −	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STEREO 1	Stereo	TV 1	1
MUSIC 2	Music	DVD 2	2

Original		Replacement	
ENTERTAIN 3	Entertain	CD-STB 3	3
MOVIE 4	Movie	VIDEO 4	4
STANDARD 5	Standard	TAPE 5	5
SELECT 6	Select	TUNER 6	6
EXTD SUR. 7	Exto Sur.	AUX-HDD 7	7
DIRECT ST. 8	Direct ST	USB 8	8
SPEAKERS 9	Speakers	BLUETOOTH 9	9
ENHANCER 0	Enhancer	HDMI-SAT 0	0
NIGHT +10	Night	-/-- GUIDE EPG	Guide / EPG / -/--
STRAIGHT ENT.	Straight	PC FAV MARKER	Fav / Marker / PC
LEVEL TITLE BAND	Title/Level	TITLE SOUND	Sound / Title
^	Up	▲	Up
SET MENU MENU SRCH MODE	Set Menu	HOME MENU	Menu / Home
A/B/C/D/E	Left/-	◀	Left
ENTER	Enter	OK	OK
A/B/C/D/E +	Right/+	▶	Right
RETURN DAB MEMORY	Return/Dab Memory	RETURN BACK	Back / Return

Original	Replacement	Original	Replacement
Down	Down		
Display	Display / Media		
System Power 2	Yellow / YouTube / Repeat		
Standby 2	Blue / Prime Video / Random		

Original		Replacement	
POWER AV	Power AV	RDS AV INPUT	AV / Input / RDS
STANDBY	Standby	SHIFT +	Shift + Power
POWER	Power		Power
CD	CD	SHIFT + CD-STB 3	Shift + 3
MD/CD-R	MD/CD-R	SHIFT + TAPE 5	Shift + 5
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
*	*	SHIFT + BLUETOOTH 9	Shift + 9
DVD	DVD	SHIFT + DVD 2	Shift + 2
DTV/CBL	DTV/CBL	SHIFT + TV 1	Shift + 1
DVR	DVR	SHIFT + USB 8	Shift + 8
V-AUX	V-AUX	SHIFT + AUX-HDD 7	Shift + 7
REC DISC SKIP	Disc Skip DVD	GOTO TEXT	Text / Goto
	Pause DVD	STEP-FREEZE	Pause / Step / Freeze
MULTI CH IN	Multi CH In	SHIFT + VIDEO 4	Shift + 4
FREQ/TEXT	I<< DVD	PRESET-	I<< / Preset-
	Play DVD	SLOW	Play / Slow
EON	>>I DVD	PRESET+	>>I / Preset+

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MODE	<< DVD	TUNE-	<< / Tune-
PTY SEEK	Stop DVD	HOLD	Stop / Hold
START	>> DVD	TUNE+	>> / Tune+
VOLUME +	Vol +	VOL +	Vol +
VOLUME -	Vol -	VOL -	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STEREO 1	1 DVD	TV 1	1
MUSIC 2	2 DVD	DVD 2	2
ENTERTAIN 3	3 DVD	CD-STB 3	3
MOVIE 4	4 DVD	VIDEO 4	4
STANDARD 5	5 DVD	TAPE 5	5
SELECT 6	6 DVD	TUNER 6	6
EXTD SUR. 7	7 DVD	AUX-HDD 7	7
DIRECT ST. 8	8 DVD	USB 8	8
SPEAKERS 9	9 DVD	BLUETOOTH 9	9
ENHANCER 0	0 DVD	HDMI-SAT 0	0

Original		Replacement		Original	Replacement
NIGHT +10	+10 DVD	-/-- GUIDE EPG	Guide / EPG / -/--		
STRAIGHT ENT.	ENT DVD	PC FAV MARKER	Fav / Marker / PC		
LEVEL TITLE BAND	Title DVD	TITLE SOUND	Sound / Title		
	Up DVD		Up		
SET MENU MENU SRCH MODE	Menu/Set Menu/Search	HOME MENU	Menu / Home		
A/B/C/D/E	Left/- DVD		Left		
ENTER	Enter DVD	OK	OK		
A/B/C/D/E	Right/+ DVD		Right		
RETURN DAB MEMORY	Return/DAB Memory DVD	RETURN BACK	Back / Return		
PRESET/CH	Down DVD		Down		
DISPLAY	Display DVD	MEDIA DISPLAY	Display / Media		

Original		Replacement	
STANDBY	Standby	SHIFT +	Shift + Power
POWER	Power		Power
CD	CD	SHIFT + CD-STB 3	Shift + 3
MD/CD-R	MD/CD-R	SHIFT + TAPE 5	Shift + 5
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
★	*	SHIFT + BLUETOOTH 9	Shift + 9
DVD	DVD	SHIFT + DVD 2	Shift + 2
DTV/CBL	DTV/CBL	SHIFT + TV 1	Shift + 1
DVR	DVR	SHIFT + USB 8	Shift + 8
V-AUX	V-AUX	SHIFT + AUX-HDD 7	Shift + 7
REC DISC SKIP	Disc Skip CD	GOTO TEXT	Text / Goto
	Pause CD	STEP-FREEZE	Pause / Step / Freeze
MULTI CH IN	Multi CH In	SHIFT + VIDEO 4	Shift + 4
FREQ/TEXT	I<< CD	PRESET-	I<< / Preset-
	Play CD	SLOW	Play / Slow
EON	>>I CD	PRESET+	>>I / Preset+
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer

Original		Replacement	
MODE	<< CD	TUNE-	<< / Tune-
PTY SEEK	Stop CD	HOLD	Stop / Hold
START	>> CD	TUNE+	>> / Tune+
+ VOLUME	Vol +	+ VOL	Vol +
VOLUME −	Vol -	VOL −	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STEREO 1	1 CD	TV 1	1
MUSIC 2	2 CD	DVD 2	2
ENTERTAIN 3	3 CD	CD-STB 3	3
MOVIE 4	4 CD	VIDEO 4	4
STANDARD 5	5 CD	TAPE 5	5
SELECT 6	6 CD	TUNER 6	6
EXTD SUR. 7	7 CD	AUX-HDD 7	7
DIRECT ST. 8	8 CD	USB 8	8
SPEAKERS 9	9 CD	BLUETOOTH 9	9
ENHANCER 0	0 CD	HDMI-SAT 0	0
NIGHT +10	+10 CD	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement		Original		Replacement	
STRAIGHT ENT.	ENT CD	PC FAV MARKER	Fav / Marker / PC				
LEVEL TITLE BAND	Title/Level/Ban	TITLE SOUND	Sound / Title				
	Up		Up				
SET MENU MENU SRCH MODE	Set Menu	HOME MENU	Menu / Home				
A/B/C/D/E	Left/-		Left				
ENTER	Enter	OK	OK				
A/B/C/D/E	Right/+		Right				
RETURN DAB MEMORY	Return/Dab	RETURN BACK	Back / Return				
PRESET/CH	Down		Down				
DISPLAY	Display CD	MEDIA DISPLAY	Display / Media				

Original	Replacement
Standby	Shift + Power
Power	Power
CD	Shift + 3
MD/CD-R	Shift + 5
Tuner	Shift + 6
*	Shift + 9
DVD	Shift + 2
DTV/CBL	Shift + 1
DVR	Shift + 8
V-AUX	Shift + 7
Multi CH In	Shift + 4
Freq/Text Tuner	I<< / Preset-
EON Tuner	>>I / Preset+
Sleep	Sleep / Timer
PTY Seek Mode	<< / Tune-
PTY Seek Start Tuner	>> / Tune+
Vol +	Vol +

Original	Replacement
Vol -	Vol -
Mute	Mute / Dimmer
1 Tuner	1
2 Tuner	2
3 Tuner	3
4 Tuner	4
5 Tuner	5
6 Tuner	6
7 Tuner	7
8 Tuner	8
9 Tuner	9
0 Tuner	0
ENT Tuner	Fav / Marker / PC
Band Tuner	Play / Slow
Up Tuner	Up
Search Mode	Red / Netflix / Search
Left/- Tuner	Left

Original		Replacement		Original	Replacement
ENTER	Enter Tuner	OK	OK		
A/B/C/D/E	Right / + Tuner		Right		
RETURN DAB MEMORY	DAB Memory	RETURN BACK	Back / Return		
PRESET/CH	Down Tuner		Down		
DISPLAY	Display Tuner	MEDIA DISPLAY	Display / Media		