Mandis shop

Denon RC-270

Original		Replacement	
POWER	Power		Power
PROG/DIRECT	Prog/Direct	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
10	10	0	0
+10	+10	-/-- GUIDE	Guide
CALL	Call	FAV PRE-CH	Pre Ch
PLAY	Play	PLAY MODE	Play
PAUSE	Pause		Pause
STOP	Stop		Stop

Original		Replacement	
REC	Rec	REC MODE	Rec
>>I	>>I		>>I
I<<	I<<		I<<
>>	>>		>>
<<	<<		<<
TIME	Time	TIMER AV	AV
CLEAR	Clear	CLEAR EXIT	Exit
ENTER	Enter	OK	Ok
TITLE	Title	DISPLAY INFO	Info
CHARACTER	Character	SETTINGS OPT	Options
EDIT	Edit	SEARCH TV/R	TV/R
REPEAT 1/ALL	Repeat 1/ALL	REPEAT TEXT	Text
REPEAT A-B	Repeat A-B	E-MANUAL D.MENU	D. Menu
RANDOM	Random	APP MEDIA	Media
EJECT	Eject	ZOOM	Eject
MEMORY REC	Memory Rec	PICTURE FORMAT	Format
SYNCHRO REC	Synchro Rec	ECO 3D	3D

https://mandisremotes.com/en/Denon/1056900-86420-replacement-remote-control-for-Denon-RC-270-00D3990473003.html