Original		Replacement	
RECEIVER	Power Receiver		Power
ENTER	Enter Receiver	OK	Ok
	Up Receiver		Up
	Down Receiver		Down
	Right Receiver		Right
	Left Receiver		Left
RETURN	Return Receiver	RETURN BACK	Back
Q SETUP	Q/Setup Receiver	HOME SMART	Smart
AUDIO HOME	Home/Audio	APP MEDIA	Media
PLAY	Play Receiver	PLAY MODE	Play
	I<< Receiver		I<<
	>>I Receiver		>>I
	<< Receiver		<<
	>> Receiver		>>
	Pause Receiver		Pause
	Stop Receiver		Stop
1	1 Receiver	1	1

Original		Replacement	
2	2 Receiver	2	2
3	3 Receiver	3	3
4	4 Receiver	4	4
5	5 Receiver	5	5
6	6 Receiver	6	6
7	7 Receiver	7	7
8	8 Receiver	8	8
9	9 Receiver	9	9
11 0	0/11 Receiver	0	0
--/-- 10 +10 D.TUN DIMMER	+10/--/--10/Dimmer/D.Tun Receive	SHIFT + -/-- GUIDE	Shift + Guide
12 CLR SLEEP	CLR/Sleep/12 Receiver	FAV PRE-CH	Pre Ch
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat Receiver	B	Green
RANDOM GAME C	Game/Yellow/Random Receiver	C	Yellow
MODE STEREO D	Stereo/Blue/Mode Receiver	D	Blue
VOL	Vol + Receiver	+ VOL	Vol +
VOL	Vol - Receiver	VOL –	Vol -

Original	Replacement
CH Disc/Album+ Receiver	Ch +
CH Disc/Album- Receiver	Ch -
Power Tv	Shift + Power
Input Tv	AV
CH+ Tv	Shift + Ch +
CH- Tv	Shift + Ch -
Up Tv	Shift + Up
Enter Tv	Shift + Ok
Down Tv	Shift + Down
Right Tv	Shift + Right
Left Tv	Shift + Left
Menu/Prev CH	Menu
Top Menu/Guide	Shift + Menu
Return Tv	Shift + Back
Q/Setup Tv	Shift + Smart
Red Tv	Options
Green Tv	Dual

Original	Replacement
Yellow Tv	Subt
Blue Tv	TV/R
1 Tv	Shift + 1
2 Tv	Shift + 2
3 Tv	Shift + 3
4 Tv	Shift + 4
5 Tv	Shift + 5
6 Tv	Shift + 6
7 Tv	Shift + 7
8 Tv	Shift + 8
9 Tv	Shift + 9
0/11 Tv	Shift + 0
+10/--/--10 Tv	Guide
CLR/Sleep/12	Shift + Pre Ch
Vol + Tv	Shift + Dual
Vol - Tv	Shift + Options
AUX	Text

Original		Replacement		Original	Replacement
TV/CD	TV/ CD	PICTURE FORMAT	For mat		
CBL/SAT	CBL/ SAT	ECO 3D	3D		
FM	FM	SHIFT +	AD SUBT Shi f t + Subt		
NET	NET	SHIFT +	APP MEDIA Shi f t + Medi a		
PC	PC	SHIFT +	SEARCH TV/R Shi f t + TV/ R		
BD/DVD	BD/ DVD	SHIFT +	REPEAT TEXT Shi f t + Text		
USB	USB	SHIFT +	TIMER AV Shi f t + AV		

Original		Replacement	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Q/Setup	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
	Right BD/DVD		Right
	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
PLAY	Play BD/DVD	PLAY MODE	Play
	Pause BD/DVD		Pause

Original		Replacement	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat BD/DVD	B	Green
RANDOM GAME C	Game/Yellow/Random BD/DVD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
-/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tuner Dimmer BD/DVD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

BD/DVD

Original		Replacement	
CBL/SAT	CBL/ SAT	REPEAT TEXT	Text
VOL	Vol + Recei ver	+ VOL	Vol +
VOL	Vol - Recei ver	VOL –	Vol -
SOURCE	Power CBL/ SAT	SHIFT +	Shi ft + Power
CH DISC	CH Di sc/ Al bum+ CBL/ SAT	+ CH	Ch +
ALBUM	CH Di sc/ Al bum- CBL/ SAT	CH –	Ch -
MENU PREV CH	Menu/ Pr ev CH CBL/ SAT	SHIFT +	Shi ft + Menu
TOP MENU GUIDE	Top Menu/ Gui de CBL/ SAT	SHIFT +	Shi ft + Opti ons
RETURN	Ret ur n CBL/ SAT	SHIFT +	Shi ft + Back
Q SETUP	Q/ Set up	SHIFT +	Shi ft + Smar t
	Up CBL/ SAT	SHIFT +	Shi ft + Up
ENTER	Ent er CBL/ SAT	SHIFT +	Shi ft + Ok
	Down CBL/ SAT	SHIFT +	Shi ft + Down
	Ri ght CBL/ SAT	SHIFT +	Shi ft + Ri ght
	Lef t CBL/ SAT	SHIFT +	Shi ft + Lef t
	Pause CBL/ SAT	SHIFT +	Shi ft + Pause
	St op CBL/ SAT	SHIFT +	Shi ft + St op

Original		Replacement	
	<< CBL/ SAT	SHIFT + CH –	Shi ft + Ch -
	>> CBL/ SAT	SHIFT + + CH	Shi ft + Ch +
PLAY	Pl ay CBL/ SAT	ECO 3D	3D
SEARCH MOVIE/TV A	Movi e Tv/ Red/ Sear ch	SOUND DUAL	Dual
REPEAT MUSIC B	Musi c/ Gr een/ Repe at CBL/ SAT	AD SUBT	Subt
RANDOM GAME C	Game/ Yel l ow/ Ran dom CBL/ SAT	TIMER AV	AV
MODE STEREO D	St er eo/ Bl ue/ Mode CBL/ SAT	PICTURE FORMAT	For mat
1	1 CBL/ SAT	SHIFT + 1	Shi ft + 1
2	2 CBL/ SAT	SHIFT + 2	Shi ft + 2
3	3 CBL/ SAT	SHIFT + 3	Shi ft + 3
4	4 CBL/ SAT	SHIFT + 4	Shi ft + 4
5	5 CBL/ SAT	SHIFT + 5	Shi ft + 5
6	6 CBL/ SAT	SHIFT + 6	Shi ft + 6
7	7 CBL/ SAT	SHIFT + 7	Shi ft + 7
8	8 CBL/ SAT	SHIFT + 8	Shi ft + 8
9	9 CBL/ SAT	SHIFT + 9	Shi ft + 9
11 0	0/ 11 CBL/ SAT	SHIFT + 0	Shi ft + 0

Original	Replacement	Original	Replacement
BD/DVD	SEARCH TV/R TV/ R		

Original		Replacement	
SOURCE	Power TV/CD		Power
CH DISC +	CH/Disc+ TV/CD	CH +	Ch +
ALBUM −	CH/Disc TV/CD	CH −	Ch -
RETURN	Return TV/CD	RETURN BACK	Back
Q SETUP	Q/Setup TV/CD	HOME SMART	Smart
AUDIO HOME	Home/Audio	APP MEDIA	Media
	Up TV/CD		Up
	Down TV/CD		Down
	Right TV/CD		Right
	Left TV/CD		Left
ENTER	Enter TV/CD	OK	Ok
⏮	I<< TV/CD	⏮	I<<
⏭	>>I TV/CD	⏭	>>I
◀◀	<< TV/CD	◀◀	<<
▶▶	>> TV/CD	▶▶	>>
PLAY	Play TV/CD	PLAY MODE ▶	Play
II	Pause TV/CD	II	Pause

Original		Replacement	
■	Stop TV/CD	■	Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat TV/CD	B	Green
RANDOM GAME C	Game/Yellow/Random TV/CD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode TV/CD	D	Blue
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9
11 0	0/11 TV/CD	0	0
--/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer TV/CD	--/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

TV/CD

Original	Replacement	Original	Replacement
VOL Vol + Recei ver	+ VOL Vol +		
VOL Vol - Recei ver	VOL – Vol -		
TV/CD TV/ CD	SEARCH TV/R TV/ R		

Original		Replacement	
RECEIVER	Power Receiver Zone 2		Power
VOL ▲	Vol + Zone 2	+ VOL	Vol +
VOL ▼	Vol - Zone 2	VOL −	Vol -
+ CH DISC	CH Disc/Album+ Zone 2	+ CH	Ch +
ALBUM −	CH Disc/Album- Zone 2	CH −	Ch -
	Up Zone 2	▲	Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2	▼	Down
	Right Zone 2	▶	Right
	Left Zone 2	◀	Left
RETURN	Return Zone 2	RETURN BACK	Back
Q SETUP	Q/Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Home/Audio Zone	APP MEDIA	Media
⏮	I<< Zone 2	⏮	I<<
⏭	>>I Zone 2	⏭	>>I
PLAY	Play Zone 2	PLAY MODE ▶	Play
▶▶	>> Zone 2	▶▶	>>

Original		Replacement	
◀◀	<< Zone 2	◀◀	<<
❚❚	Pause Zone 2	❚❚	Pause
■	Stop Zone 2	■	Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat Zone 2	B	Green
RANDOM GAME C	Game/Yellow/Random Zone 2	C	Yellow
MODE STEREO D	Stereo/Blue/Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9
11 0	0/11 Zone 2	0	0

Original	Replacement	Original	Replacement
+10/ - - / - - 10/ D. Tu Di mmer Zone 2	Gui de		
CLR/ Sl eep/ 12	Pr e Ch		