| Original | Replacement |
|---|---|
| Standby / On | Power |
| Volume + | Vol + |
| Volume - | Vol - |
| Muting | Mute |
| Timer | AV |
| Sleep | Sleep |
| MP3 / FM Mode | Media |
| Function | Smart |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |

| Original | Replacement |
|---|---|
| 0 | 0 |
| MP3 Folder - / Preset - | Ch - |
| MP3 Folder - / Preset - | Down |
| MP3 Folder + / Preset + | Ch + |
| MP3 Folder + / Preset + | Up |
| Band | Menu |
| Memory | Info |
| Shuffle | Ok |
| Repeat | Text |
| I<< << / Tuning - | << |
| I<< << / Tuning - | I<< |
| I<< << / Tuning - | Left |
| >> >>I / Tuning | >> |
| >> >>I / Tuning | >>I |
| >> >>I / Tuning | Right |
| Stop | Stop |
| Play / Pause | Play |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Play / Pause | Pause | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |