Mandis shop

Philips RC0710401

Original		Replacement	
TIME	Time	TIMER SLEEP	Sleep / Timer
	Power		Power
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio /
FADE	Fade	DIMMER MUTE	Mute / Dimmer
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
HIGHLIGHT	Highlight	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Original		Replacement	
VOLUME	Vol-	VOL	Vol-
VOLUME +	Vol+	+ VOL	Vol+
PREV.	Prev/I<	PRESET-	I<< / Preset-
PLAY	Play	SLOW	Play / Slow
NEXT	>I/Next	PRESET+	>>I / Preset+
STOP	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
	>>	TUNE+	>> / Tune+

https://mandisremotes.com/en/Philips/1058914-91307-replacement-remote-control-for-Philips-RC07104-01-313922880441.html