Original	Replacement	Original	Replacement
On/Off	Power	C/CH	Setup / OPT /
Audio Off	Mute / Dimmer	Menu	Menu / Home
Play	Play / Slow	Menu Up	Up
Pause	Pause / Step / Freeze	Angle	Info / Angle
Stop	Stop / Hold	Menu Left	Left
Record	Rec / Rec Mode	OK Enter	OK
Rewind	<< / Tune-	Menu Right	Right
F. Forward	>> / Tune+	Clear/00:00	Exit / Cancel / Clear
Prev.	I<< / Preset-	Menu Down	Down
Next	>>I / Preset+	Return	Back / Return
Title	Sound / Title	Volume+	Vol +
Audio	Audio / Lang I/II	Auto/Track	Smart / List
Subt.	Subtitle / EQ	Slow Up	CH+ / Page+
Open/Close	Eject / Surround	Volume-	Vol -
Zoom	Zoom / Size	Display	Display / Media
Progr.	TV/Radio /	Slow Down	CH- / Page-
Top Menu	D.Menu / Top Menu	1	1

Original	Replacement	Original	Replacement
2	DVD 2 2		
3	CD - STB 3 3		
4	VIDEO 4 4		
5	TAPE 5 5		
6	TUNER 6 6		
7	AUX - HDD 7 7		
8	USB 8 8		
9	BLUETOOTH 9 9		
0	HDMI - SAT 0 0		
Repeat / 1/ All	APP REPEAT Green / APP / Repeat		
Random	Prime Video RANDOM Blue / Prime Video / Random		