Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/Sat	1	1
MEDIA PLAYER	Media Player	2	2
Blu-ray/ DVD	Blu-ray/DVD	3	3
GAME	Game	4	4
AUX	AUX	5	5
TUNER	Tuner	6	6
iPod/USB	iPod/USB	7	7
TV AUDIO	Tv Audio	8	8
CD	CD	9	9
ONLINE MUSIC	Online Music	-/-- GUIDE	Guide
Bluetooth	Bluetooth	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
CH / PAGE	CH/Page+	+ CH	Ch +
CH / PAGE	CH/Page-	CH −	Ch -
ECO	Eco	ECO 3D	3D

Original		Replacement	
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TUNE−	I<</Tune-		I<<
▶/II	Play	PLAY MODE ▶	Play
▶/II	Pause	II	Pause
TUNE+	>>I/Tune+		>>I
1	Smart Select 1	E-MANUAL D.MENU	D. Menu

Original		Replacement		Original		Replacement	
SMART 2	Smart Select 2	REPEAT TEXT	Text				
SELECT 3	Smart Select 3	ZOOM ⏏	Eject				
4	Smart Select 4	TIMER AV	AV				
MOVIE	Green/Movie	B	Green				
SOUND MUSIC	Red/Music	A	Red				
MODE GAME	Blue/Game	D	Blue				
PURE	Yellow/Pure	C	Yellow				