Original		Replacement	
	Power		Power
	Text / Display	REPEAT TEXT	Text
	Call / Index	DISPLAY INFO	Info
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Recall	FAV PRE-CH	Pre Ch
	Input	TIMER AV	AV
MENU DVD MENU	Menu / DVD	TOP MENU MENU	Menu
	→| [/] |←	ECO 3D	3D

Original		Replacement	
	Aspect	PICTURE FORMAT	Format
EXIT	Exit	CLEAR EXIT	Exit
P▲	Up / P+	▲	Up
P▲	Up / P+	+ CH	Ch +
P▼	Down / P-	▼	Down
P▼	Down / P-	CH –	Ch -
	Right / Vol +	▶	Right
	Right / Vol +	+ VOL	Vol +
	Left / Vol -	◀	Left
	Left / Vol -	VOL –	Vol -
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
I/II	I/II	SOUND DUAL	Dual
	Audio	SHIFT + SOUND DUAL	Shift + Dual

Original		Replacement		Original	Replacement
	Mute	MUTE	Mute		
	Play / Reveal	HOME SMART	Smart		
	Stop / Hold		Stop		
	Play / Reveal	PLAY MODE	Play		
	<< / Size		<<		
	>> / [⏻] / [⏻/X]		>>		

Original		Replacement		Original	Replacement
	Power		Power		
	Menu DVD		Menu		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		Ok		
	Pause		Pause		
	Play		Play		
	<<		<<		
	>>		>>		
	Open/Close		Eject		
	Stop		Stop		
	I <<		I <<		
	>>I		>>I		

Original		Replacement	
	Power		Power
	Pause		Pause
	Play	PLAY MODE	Play
	<<		<<
	>>		>>
	Eject	ZOOM	Eject
	Stop		Stop
	I <<		I <<
	>>I		>>I

Original	Replacement