Mandis shop

REMCON278

Original		Replacement	
	Power		Power
TV/♫	TV / Radio	SEARCH TV/R	TV/R
MUTE	Mute	MUTE	Mute
i	i	DISPLAY INFO	Info
ALT	ALT	RETURN BACK	Back
M/A	M/A	HOME SMART	Smart
TELETEXT	Teletext	REPEAT TEXT	Text
EXIT	Exit	CLEAR EXIT	Exit
MENU	Menu	TOP MENU MENU	Menu
FAV	FAV	FAV PRE-CH	Pre Ch
P/L	P/L	APP MEDIA	Media
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
	Vol +	+ VOL	Vol +

Original		Replacement	
	Vol -	VOL –	Vol -
PG+	PG+	+ CH	Ch +
PG-	PG-	CH –	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

https://mandisremotes.com/en/1060334-48281-replacement-remote-control-for-REMCON278.html