Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
MENU DISPLAY	Display Menu	DISPLAY INFO	Info
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
	Up		Up
	Left		Left

Original		Replacement	
OK	OK	OK	Ok
	Right		Right
	Down		Down
	I <<		I <<
	I <<		<<
	>>I		>>I
	>>I		>>
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PAUSE	Pause		Pause
DISC	DISC	B	Green
TV	TV	A	Red
TUNER	TUNER	C	Yellow
AUX/DI	AUX/DI	D	Blue
SUBTITLE	Subtitle	AD SUBT	Subt
AUDIO	Audio	SOUND DUAL	Dual
ZOOM	Zoom	ZOOM	Eject

Original		Replacement		Original	Replacement
SETUP	Set up	TOP MENU / MENU	Menu		
REPEAT	Repeat	REPEAT / TEXT	Text		
PROG	Prog	SHIFT + PROG / SLEEP	Shift + Sleep		
SLEEP	Sleep	PROG / SLEEP	Sleep		
MUTE	Mute	MUTE	Mute		
SOUND	Sound	SHIFT + SOUND / DUAL	Shift + Dual		
SURR	SURR	PICTURE / FORMAT	Format		
TV VOL +	TV Vol +	+ CH	Ch +		
TV VOL −	TV Vol -	CH −	Ch -		

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
MENU DISPLAY	Display Menu	DISPLAY INFO	Info
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
	Up		Up
	Left		Left
OK	OK	OK	Ok

Original		Replacement	
	Right		Right
	Down		Down
	I<<		I<<
	I<<		<<
	>>I		>>
	>>I		>>I
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
DISC	DISC	B	Green
TV	TV	A	Red
TUNER	TUNER	C	Yellow
AUX/DI	AUX/DI	D	Blue
SETUP	Setup	TOP MENU MENU	Menu
MUTE	Mute	MUTE	Mute
SOUND	Sound	SOUND DUAL	Dual
SURR	SURR	PICTURE FORMAT	Format
TV VOL +	TV Vol +	CH +	Ch +

Original	Replacement	Original	Replacement
TV Vol -	Ch -		

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
MENU DISPLAY	Display Menu	DISPLAY INFO	Info
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
	Up		Up
	Left		Left
OK	OK	OK	Ok

Original		Replacement	
	Right		Right
	Down		Down
	I<<		I<<
	I<<		<<
	>>I		>>I
	>>I		>>
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
DISC	DISC	B	Green
TV	TV	A	Red
TUNER	TUNER	C	Yellow
AUX/DI	AUX/DI	D	Blue
PROG	Prog	PROG SLEEP	Sleep
MUTE	Mute	MUTE	Mute
SOUND	Sound	SOUND DUAL	Dual
SURR	SURR	PICTURE FORMAT	Format
TV VOL +	TV Vol +	+ CH	Ch +

Original	Replacement	Original	Replacement
TV Vol -	Ch -		

Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
MENU DISPLAY	Display Menu	DISPLAY INFO	Info
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
	Up		Up
	Left		Left
OK	OK	OK	Ok

Original		Replacement	
	Right		Right
	Down		Down
	I<<		I<<
	I<<		<<
	>>I		>>I
	>>I		>>
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PAUSE	Pause		Pause
DISC	DISC	B	Green
TV	TV	A	Red
TUNER	TUNER	C	Yellow
AUX/DI	AUX/DI	D	Blue
PROG	Prog	PROG SLEEP	Sleep
SETUP	Setup	TOP MENU MENU	Menu
MUTE	Mute	MUTE	Mute
SURR	SURR	PICTURE FORMAT	Format