Mandis shop

MX009

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| POWER | Power | | Power | | |
| MUTE | Mute | MUTE | Mute | | |
| FRONT+ | Front+ | | Up | | |
| FRONT- | Front- | | Down | | |
| CEN+ | Cen+ | | Right | | |
| CEN- | Cen- | | Left | | |
| SURR+ | Surr+ | + CH | Ch + | | |
| SURR- | Surr- | CH − | Ch - | | |
| TRE+ | Tre+ | 1 | 1 | | |
| TRE- | Tre- | 4 | 4 | | |
| BASS+ | Bass+ | 2 | 2 | | |
| BASS- | Bass- | 5 | 5 | | |
| SUB+ | Sub+ | 3 | 3 | | |
| SUB- | Sub- | 6 | 6 | | |
| VOL+ MASTER | Master Vol+ | + VOL | Vol + | | |
| MASTER VOL- | Master Vol- | VOL − | Vol - | | |

https://mandisremotes.com/en/MxOnda/1060879-91184-replacement-remote-control-for-MxOnda-MX009.html