Original		Replacement	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	-/-- GUIDE	Guide
PRE-CH	[≡o] / PRE-CH	FAV PRE-CH	Pre Ch
TV	[ ] / TV	SEARCH TV/R	TV/R
CH MGR	CH MGR	HOME SMART	Smart
SLEEP	Sleep	PROG SLEEP	Sleep

Original		Replacement	
PC	PC	APP MEDIA	Media
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
P	P+	+ CH	Ch +
	P-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
PIP	[≡+] / PIP	ECO 3D	3D
INFO	[≡?] / Info	DISPLAY INFO	Info
TX/MIX	TTX/MIX	REPEAT TEXT	Text
P.MODE	Red/P.Mode	A	Red

Original		Replacement		Original	Replacement
S.MODE	Green/ S. Mode	B	Green		
STILL	Yellow/ Still	C	Yellow		
P.SIZE	Blue/ P. Size	D	Blue		
E.SAVING	E. Saving	SETTINGS OPT	Options		
	[≡♦]	PICTURE FORMAT	Format		
SOURCE	[≡♦] / Source	ZOOM	Eject		
DUAL I-II	I-II / Dual	SOUND DUAL	Dual		
SRS	(·) / SRS	AD SUBT	Subt		
POSITION	[^] / Position	RETURN BACK	Back		
P	P Up		>>		
P	P Down		<<		