Original		Replacement	
	Power		Power
	Sleep	PROG SLEEP	Sleep
LINE 1	Line 1	1	1
LINE 2	Line 2	2	2
LINE 3	Line 3	3	3
CD	CD	4	4
TUNER	Tuner	5	5
BAND	Band	SEARCH TV/R	TV/R
MEMORY	Memory	REC MODE	Rec
INFO	Info	DISPLAY INFO	Info
TUNING >>	Tuning >>	D	Blue
<< TUNING	<< Tuning	C	Yellow
PRESET >	Preset >	+ CH	Ch +
< PRESET	< Preset	CH −	Ch -
TREBLE +	Treble+	7	7
TREBLE −	Treble-	-/-- GUIDE	Guide
BASS +	Bass+	8	8

Original		Replacement	
BASS −	Bass-	0	0
A SPEAKERS	Speakers A	A	Red
SPEAKERS B	Speakers B	B	Green
BALANCE R	Balance R	AD SUBT	Subt
L BALANCE	Balance L	PICTURE FORMAT	Format
BLUETOOTH	Up/Bluetooth		Up
▶II	Down/Play/Paus		Down
▶▶I	Right/>>I		Right
I◀◀	Left/I<<		Left
ENTER	Enter	OK	Ok
MENU	Menu	TOP MENU MENU	Menu
DIMMER	Dimmer	APP MEDIA	Media
VOLUME +	Volume+	+ VOL	Vol +
VOLUME −	Volume-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
	Stop	■	Stop
	Pause	II	Pause

Original		Replacement	
	Play	PLAY MODE	Play
DISC SKIP	Disc Skip	HOME SMART	Smart
	I<<		I<<
	>>I		>>I
	Open/Close	ZOOM	Eject
	<<		<<
	>>		>>

Original	Replacement