Original	Replacement	Original	Replacement
Standby	Shift + Power	System Memory	Shift + 2
Power	Power	System Memory	Shift + 3
Multi	Guide / EPG / -/--	System Memory	Shift + 4
V-AUX	7	Title	Sound / Title
Phono	Shift + Sound / Title	Menu	Menu / Home
Dock	Zoom / Size	Vol +	Vol +
BD/HD DVD	Shift + 5	Up	Up
DVD	2	Left	Left
CD	3	Enter	OK
MD/CD-R	Text / Goto	Right	Right
CBL/SAT	Shift + TV/Radio / Program	Down	Down
TV	TV/Radio /	Vol -	Vol -
DVR	D. Menu / Top	Return	Back / Return
VCR	4	Display	Display / Media
Tuner	6	Mute	Mute / Dimmer
USB	8	1/Classical	1
System Memory	Shift + 1	2/Live Club	Shift + Display / Media

Original	Replacement	Original	Replacement
ENTERTAIN 3 — 3/ Entertain	LIST SMART — Smart / List		
MOVIE 4 — 4/ Movie	SHIFT + LIST SMART — Shift + Smart / List		
STEREO 5 — 5/ Stereo	TAPE 5 — 5		
ENHANCER 6 — 6/ Enhancer	SHIFT + TUNER 6 — Shift + 6		
SUR. DECODE 7 — 7/ Sur. Decode	SHIFT + AUX - HDD 7 — Shift + 7		
STRAIGHT 8 — 8/ Straight	SHIFT + USB 8 — Shift + 8		
9 — 9	BLUETOOTH 9 — 9		
0 — 0	HDMI - SAT 0 — 0		
EXTD SUR. +10 — +10/ EXTD Sur.	PC FAV MARKER — Fav / Marker / PC		
PURE DIRECT ENT — ENT/ Pure Direct	SHIFT + OK — Shift + OK		
INFO + — Info	ANGLE INFO — Info / Angle		
LEVEL + — Level	OPT-TOOLS SETUP — Setup / OPT /		
SLEEP MUTE — Sleep	TIMER SLEEP — Sleep / Timer		
AUDIO SEL AUDIO — Audio/ Audio Se	LANG I/II AUDIO — Audio / Lang I/II		
3D DSP — 3D DSP	FORMAT PICTURE — Picture / Format		

Original		Replacement		Original		Replacement	
POWER	Power		Power		<<	TUNE-	<< / Tune-
TITLE BAND	Title	TITLE SOUND	Sound / Title	EON	>>	TUNE+	>> / Tune+
MENU SRCH MODE	Menu	HOME MENU	Menu / Home	MODE – PTY S	I <<	PRESET-	I << / Preset-
VOLUME +	Vol +	+ VOL	Vol +	SEEK – START	>>I	PRESET+	>>I / Preset+
	Up		Up	CLASSICAL 1	1	TV 1	1
	Left		Left	LIVE/CLUB 2	2	DVD 2	2
ENTER	Enter	OK	OK	ENTERTAIN 3	3	CD-STB 3	3
A-E	Right		Right	MOVIE 4	4	VIDEO 4	4
	Down		Down	STEREO 5	5	TAPE 5	5
–	Vol -	VOL –	Vol -	ENHANCER 6	6	TUNER 6	6
RETURN MEMORY	Return	RETURN BACK	Back / Return	SUR. DECODE 7	7	AUX-HDD 7	7
PARAMETER DISPLAY	Display	MEDIA DISPLAY	Display / Media	STRAIGHT 8	8	USB 8	8
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	9	9	BLUETOOTH 9	9
REC	Rec	REC MODE	Rec / Rec Mode	0	0	HDMI-SAT 0	0
	Pause	STEP-FREEZE	Pause / Step / Freeze	EXTD SUR. +10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
	Play	SLOW	Play / Slow	PURE DIRECT ENT	ENT	SHIFT + OK	Shift + OK
	Stop	HOLD	Stop / Hold	AUDIO SEL AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Replacement	
POWER	Power		Power
TITLE BAND	Band	TOP MENU D.MENU	D. Menu / Top
MENU SRCH MODE	SRCH Mode	OPT-TOOLS SETUP	Setup / OPT /
VOLUME +	Vol +	+ VOL	Vol +
	UP Preset / CH+		Up
	Left		Left
ENTER	Enter	OK	OK
A-E	Right / A-E		Right
	Down		Down
–	Vol -	VOL –	Vol -
RETURN MEMORY	Memory	LIST SMART	Smart / List
PARAMETER DISPLAY	Parameter	HOME MENU	Menu / Home
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
REC	Rec	REC MODE	Rec / Rec Mode
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold

Original		Replacement	
	<<	TUNE-	<< / Tune-
EON	>>	TUNE+	>> / Tune+
MODE – PTY	I <<	PRESET-	I << / Preset-
SEEK – START	>>I	PRESET+	>>I / Preset+
CLASSICAL 1	1	TV 1	1
LIVE/CLUB 2	2	DVD 2	2
ENTERTAIN 3	3	CD-STB 3	3
MOVIE 4	4	VIDEO 4	4
STEREO 5	5	TAPE 5	5
ENHANCER 6	6	TUNER 6	6
SUR. DECODE 7	7	AUX-HDD 7	7
STRAIGHT 8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
EXTD SUR. +10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
PURE DIRECT ENT	ENT	SHIFT	+ OK Shift + OK
AUDIO SEL AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original	Replacement	Original	Replacement
Power	Power	Down	Down
Mute	Mute / Dimmer	Return	Back / Return
Play	Play / Slow	Vol +	Vol +
Pause	Pause / Step / Freeze	ENT	Smart / List
Stop	Stop / Hold	Vol -	Vol -
Rec	Rec / Rec Mode	Display	Display / Media
<<	<< / Tune-	1	1
>>	>> / Tune+	2	2
I <<	I << / Preset-	3	3
>>I	>>I / Preset+	4	4
Title	Sound / Title	5	5
Audio	Audio / Lang I/II	6	6
Menu	Menu / Home	7	7
Up	Up	8	8
Left	Left	9	9
Enter	OK	+10	Guide / EPG / -/--
Right	Right	0	0

Original	Replacement	Original	Replacement
+10 Multi	Fav / Marker / PC	Down Multi	Shift + Down
Power Multi	Shift + Power	Return Multi	Shift + Back / Return
Play Multi	Shift + Play /	ENT Multi	Shift + Smart / List
Pause Multi	Shift + Pause / Step /	Display Multi	Shift + Display / Media
Stop Multi	Shift + Stop /	1 Multi	Shift + 1
Rec Multi	Shift + Rec / Rec Mode	2 Multi	Shift + 2
<< Multi	Shift + << /	3 Multi	Shift + 3
>> Multi	Shift + >> /	4 Multi	Shift + 4
I << Multi	Shift + I << / Preset-	5 Multi	Shift + 5
>>I Multi	Shift + >>I / Preset+	6 Multi	Shift + 6
Title Multi	Shift + Sound / Title	7 Multi	Shift + 7
Audio Multi	Shift + Audio / Lang I/II	8 Multi	Shift + 8
Menu Multi	Shift + Menu /	9 Multi	Shift + 9
Up Multi	Shift + Up	0 Multi	Shift + 0
Left Multi	Shift + Left		
Enter Multi	Shift + OK		
Right Multi	Shift + Right		