# Mandis shop

VEQ0910

| Original | | Replacement | |
|---|---|---|---|
| VTR | VTR | | Power |
| CLOCK/ COUNTER | Clock/Counter | YouTube / REPEAT A-B | Yellow / YouTube / Repeat |
| RESET | Reset | CLEAR / EXIT / CANCEL | Exit / Cancel / Clear |
| MEMORY/ REPEAT/SEARCH | Memory/Repeat/Search | APP / REPEAT | Green / APP / Repeat |
| AUDIO OUT | Audio Out | DIMMER / MUTE | Mute / Dimmer |
| REV.PLAY | Rev. Play | SURROUND | Eject / Surround |
| REC | Rec | REC MODE | Rec / Rec Mode |
| PAUSE/STILL | Pause/Still | STEP - FREEZE | Pause / Step / Freeze |
| STOP | Stop | HOLD | Stop / Hold |
| STILL ADV | Still Adv | PRESET+ | >>I / Preset+ |
| REW/ | << | TUNE- | << / Tune- |
| PLAY/x2 | Play | SLOW | Play / Slow |
| /FF | >> | TUNE+ | >> / Tune+ |
| - | Search - | CH PAGE - | CH- / Page- |
| SEARCH | Search | NETFLIX / SEARCH | Red / Netflix / Search |
| + | Search + | + CH PAGE | CH+ / Page+ |
| 1 | 1 | TV 1 | 1 |

| Original | | Replacement | |
|---|---|---|---|
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| TIME S | Time Search | Prime Video / RANDOM | Blue / Prime Video / Random |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| MONITOR | Monitor | MEDIA / DISPLAY | Display / Media |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| REMAIN | Remain | LIST / SMART | Smart / List |
| AV 0 | 0/AV | HDMI - SAT 0 | 0 |
| AV 0 | 0/AV | RDS / AV INPUT | AV / Input / RDS |
| -/-- | -/-- | -/-- / GUIDE EPG | Guide / EPG / -/-- |
| INDEX - | Index | ANGLE / INFO | Info / Angle |
| WRITE - | Write | HOME / MENU | Menu / Home |
| ERASE | Erase | RETURN / BACK | Back / Return |

https://mandis.tv/en/Panasonic/1637-930-replacement-remote-control-for-Panasonic-VEQ0910.htm