Mandis shop

Samsung AH59-02350A (DVD)

Original	Replacement	Original	Replacement
Power	Power	>>I	>>I
Function	AV	<<	<<
Eject	Eject	>>	>>
Sleep	Sleep	Stop	Stop
1 / RDS Displa	1	Play	Play
2	2	Pause	Pause
3 / TA	3	Vol +	Vol +
4 / PTY -	4	Vol -	Vol -
5 / PTY Search	5	Mute	Mute
6 / PTY +	6	V. Sound	Subt
7	7	Tuning / CH +	Ch +
8	8	Tuning / CH -	Ch -
9	9	Disc Menu	D. Menu
0	0	Menu	Menu
Full Screen	SHIFT + ZOOM Shift + Eject	Title Menu / PopUp Menu	SHIFT + TOP MENU Shift + Menu
Repeat	Text	Tools	Options
I <<	I <<	Info	Info

Original	Replacement
Up	Up
Left	Left
Enter	Ok
Right	Right
Down	Down
Return	Back
Exit	Exit
Red	Red
Green	Green
Yellow / Tuner Memory	Yellow
Blue / Mo/St	Blue
Smart Hub	Smart
Search	SHIFT + SEARCH TV/R Shift + TV/R
S/W Level	List
vTuner	TV/R
2D → 3D	Format
3D Sound	3D

Original	Replacement
	SHIFT + SOUND DUAL Shift + Dual
DSP	SOUND DUAL Dual

Original		Replacement	
POWER	Power		Power
FUNCTION TV SOURCE	TV Source	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
RDS DISPLAY 1	1	1	1
2	2	2	2
TA 3	3	3	3
PTY- 4	4	4	4
PTY SEARCH 5	5	5	5
PTY+ 6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
⏮	I <<	⏮	I <<
⏭	>>I	⏭	>>I
⏪	<<	⏪	<<
⏩	>>	⏩	>>

Original		Replacement	
■	Stop	■	Stop
▶	Play	PLAY MODE ▶	Play
⏸	Pause	⏸	Pause
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
TUNING / CH	CH+	+ CH	Ch +
TUNING / CH	CH-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left

Original		Replacement		Original	Replacement
	Enter	OK	Ok		
A	Red	A	Red		
B	Green	B	Green		
TUNER MEMORY C	Yellow/Tuner	C	Yellow		
MO/ST D	Blue/Mo/St	D	Blue		
SMART HUB	Smart HUB	HOME SMART	Smart		
SEARCH	Search	SEARCH TV/R	TV/R		
2D→3D	2D-3D	ECO 3D	3D		