Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	PIP		Info / Angle
	4		4
	5		5
	6		6
	[<>]		Picture / Format
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	Mute		Mute / Dimmer

Original		Replacement	
	i / OSD		Display / Media
	Z/ Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red/ Image/ I>		Red / Netflix / Search
	Green/ Timer		Green / APP / Repeat

Original		Replacement		Original		Replacement	
	Play	SLOW	Play / Slow				
	Yellow/Pause	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
	Blue/Sound	Prime Video RANDOM	Blue / Prime Video / Random				
	Stop	HOLD	Stop / Hold				
	Blue/Sound	TITLE SOUND	Sound / Title				

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	0		0
	i / OSD		Display / Media

Original		Replacement	
	Disc Menu		D. Menu / Top
	Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red/Picture		Picture / Format
	Red/Picture		Red / Netflix / Search

Original	Replacement	Original	Replacement
Green / Timer	TIMER SLEEP — Sleep / Timer		
Play	SLOW — Play / Slow		
Green / Timer	APP REPEAT — Green / APP / Repeat		
Yellow/Pause	YouTube REPEAT A-B — Yellow / YouTube / Repeat		
Pause	STEP-FREEZE — Pause / Step / Freeze		
Blue/Sound	TITLE SOUND — Sound / Title		
Stop	HOLD — Stop / Hold		
Blue/Sound	Prime Video RANDOM — Blue / Prime Video / Random		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	>I		>>I / Preset+
	7		7
	8		8
	9		9
	?		Smart / List
	I <		I << / Preset-
	0		0
	Mute		Mute / Dimmer

Original		Replacement	
	i / OSD		Display / Media
	Z/ Disc Menu		Menu / Home
	Up		Up
	P+		CH+ / Page+
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	Down		Down
	P-		CH- / Page-
	TV- G		Guide / EPG / -/--
	>>		>> / Tune+
	Red/ Image/ I >		Red / Netflix / Search
	Red/ Image/ I >		Shift + Play / Slow

Original	Replacement	Original	Replacement
Green/Timer	APP REPEAT Green / APP / Repeat		
Play	SLOW Play / Slow		
Green/Timer	TIMER SLEEP Sleep / Timer		
Pause	STEP-FREEZE Pause / Step / Freeze		
Yellow/Pause	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue/Sound	Prime Video RANDOM Blue / Prime Video / Random		
Stop	HOLD Stop / Hold		
Blue/Sound	TITLE SOUND Sound / Title		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	PIP/Audio		Audio / Lang I/II
	4		4
	5		5
	6		6
	[<>]		Zoom / Size
	7		7
	8		8
	9		9
	?		Smart / List
	I<		I<< / Preset-
	>I		>>I / Preset+
	0		0
	i/OSD		Display / Media

Original		Replacement	
	Z/Disc Menu		Menu / Home
	P+		CH+ / Page+
	Up		Up
	Left		Left
	Vol -		Vol -
	OK		OK
	Right		Right
	Vol +		Vol +
	TXT		Text / Goto
	<<		<< / Tune-
	P-		CH- / Page-
	Down		Down
	TV-G		Guide / EPG / -/--
	>>		>> / Tune+
	Red/Image/I>		Picture / Format
	Red/Image/I>		Red / Netflix / Search
	Green/Timer		Green / APP / Repeat

Original		Replacement		Original		Replacement	
	Play	SLOW	Play / Slow				
	Green/Timer	TIMER SLEEP	Sleep / Timer				
	Yellow/Pause	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
	Blue/Sound	Prime Video RANDOM	Blue / Prime Video / Random				
	Stop	HOLD	Stop / Hold				
	Blue/Sound	TITLE SOUND	Sound / Title				