Mandis shop

JVC HR-D300

Original	Replacement	Original	Replacement
Power	Power		
TV PR-	CH- / Page-		
PR-	Left		
TV P-	Down		
TV PR+	CH+ / Page+		
PR+	Right		
TV P+	Up		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		
Pause	Pause / Step / Freeze		

https://mandisremotes.com/en/JVC/1065143-95721-replacement-remote-control-for-JVC-HR-D300.html