Original	Replacement	Original	Replacement
Power	Power	Play	Play / Slow
Open/Close	Eject / Surround	Pause/Step	Pause / Step / Freeze
1	1	Stop	Stop / Hold
2	2	DVD Menu	D. Menu / Top
3	3	Title	Sound / Title
4	4	Up	Up
5	5	Enter	OK
6	6	Down	Down
7	7	Right	Right
8	8	Left	Left
9	9	Return	Back / Return
0	0	Display	Display / Media
Clear	Exit / Cancel / Clear	Audio	Audio / Lang I/II
<<	<< / Tune-	Subtitle	Subtitle / EQ
>>	>> / Tune+	Angle	Info / Angle
I <<	I << / Preset-	Setup	Setup / OPT /
>>I	>>I / Preset+	Marker	Fav / Marker / PC

Original	Replacement	Original	Replacement
Search	Red / Netflix / Search		
Program	Shift + TV/ Radio / Program		
Zoom	Zoom / Size		
Repeat	Green / APP / Repeat		
A-B	Yellow / YouTube / Repeat		
Resolution	TV/ Radio /		
Karaoke ECHO	Blue / Prime Video / Random		
Power Tv	Shift + Power		
AV Tv	AV / Input / RDS		
PR/ CH+ Tv	CH+ / Page+		
PR/ CH- Tv	CH- / Page-		
Vol + Tv	Vol +		
Vol - Tv	Vol -		