Mandis shop

Panasonic VEQ1195

Original	Replacement
Operation	Power
Audio Out	Mute / Dimmer
Rec	Rec / Rec Mode
Pause / Still	Pause / Step / Freeze
Still ADV	Right
Stop	Stop / Hold
Rew	<< / Tune-
FF	>> / Tune+
Play	Play / Slow
Slow	OK
Slow	Shift + Play /
Slow-	Down
Slow+	Up

Original	Replacement