Original		Replacement		Original		Replacement	
ON	On		Power		Up		Up
STANDBY	Standby	SHIFT +	Shift + Power	MENU	Menu	HOME MENU	Menu / Home
OPEN/ CLOSE	Open/ Close	SURROUND	Eject / Surround		Left		Left
1	1	TV 1	1	ENTER	Enter	OK	OK
2	2	DVD 2	2		Right		Right
3	3	CD - STB 3	3	RETURN	Return	RETURN BACK	Back / Return
PLAY MODE	Play Mode	PC FAV MARKER	Fav / Marker / PC		Down		Down
4	4	VIDEO 4	4	SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
5	5	TAPE 5	5	AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
6	6	TUNER 6	6	ANGLE	Angle	ANGLE INFO	Info / Angle
DISPLAY	Display	MEDIA DISPLAY	Display / Media	SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
7	7	AUX - HDD 7	7	ZOOM	Zoom	SIZE ZOOM	Zoom / Size
8	8	USB 8	8		Stop	HOLD	Stop / Hold
9	9	BLUETOOTH 9	9		Play	SLOW	Play / Slow
0	0	HDMI - SAT 0	0		Pause	STEP - FREEZE	Pause / Step / Freeze
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear		<</ ◁ / ◁ I	TUNE-	<< / Tune-
TOP MENU	Top Menu	TOP MENU D.MENU	D. Menu / Top Menu		I I >/ I >/ >>	TUNE+	>> / Tune+

Original		Replacement		Original	Replacement
	I <<	PRESET-	I << / Preset -		
	>>I	PRESET+	>>I / Preset +		