Mandis shop

RM-SCEX1

Original	Replacement
Power	Power
Play CD	Play / Slow
Pause CD	Pause / Step / Freeze
Stop CD	Stop / Hold
<<	<< / Tune-
>>	>> / Tune+
I<<⁄-	I<< / Preset-
>>I⁄+	>>I / Preset+
Stereo/Mono	Audio / Lang I/II
Open/Close	Eject / Surround
Tuning Mode	Picture / Format
Tuner/Band	TV/Radio /
Function	Menu / Home
Up/Memory	Up
Left/Timer Set	Left
Enter/On/Off	OK
Right/Timer	Right

Original	Replacement
Down/Sleep	Down
Vol+	Vol+
DSG	Smart / List
Vol-	Vol-
Display	Display / Media
Repeat	Green / APP / Repeat
Play Mode	Blue / Prime Video / Random
Surround	Shift + Eject / Surround

Select

https://mandisremotes.com/en/Sony/1066154-95747-replacement-remote-control-for-Sony-RM-SCEX1.html