| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| TUNER | TUNER | SHIFT + TUNER 6 | Shift + 6 | ▶ | Play | SLOW ▶ | Play / Slow |
| POWER | Power | POWER | Power | ⏸ | Pause | STEP-FREEZE ⏸ | Pause / Step / Freeze |
| EJECT | Eject | SURROUND ⏏ | Eject / Surround | PROG./CLEAR | Program | PROGRAM TV/RADIO | TV/Radio / |
| USB | USB | SHIFT + USB 8 | Shift + 8 | ◀◀ | << | TUNE- ◀◀ | << / Tune- |
| DISC | Disc | SHIFT + DVD 2 | Shift + 2 | ⏮ | I<< | PRESET- ⏮ | I<< / Preset- |
| MOBILE | Mobile | SHIFT + TV 1 | Shift + 1 | ⏭ | >>I | PRESET+ ⏭ | >>I / Preset+ |
| DIMMER | Dimmer | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer | ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer | MENU/LIST | Menu / List | HOME MENU | Menu / Home |
| REPEAT | Repeat | APP REPEAT | Green / APP / Repeat | HOME | Home | TOP MENU D.MENU | D.Menu / Top |
| A-B | A-B | YouTube REPEAT A-B | Yellow / YouTube / Repeat | DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| MARKER | Marker | PC FAV MARKER | Fav / Marker / PC | PRESET + | Up / Preset+ | ▲ | Up |
| SEARCH | Search | NETFLIX SEARCH | Red / Netflix / Search | PRESET + | Up / Preset+ | SHIFT + PRESET+ ⏭ | Shift + >>I / Preset+ |
| TITLE | Title | TITLE SOUND | Sound / Title | RETURN | Return | RETURN BACK | Back / Return |
| ZOOM | Zoom | SIZE ZOOM | Zoom / Size | TUN.– | Left / Tun- | ◀ | Left |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II | TUN.– | Left / Tun- | SHIFT + TUNE- ◀◀ | Shift + << / |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ | ENTER | Enter | OK | OK |
| ■ | Stop | HOLD ■ | Stop / Hold | TUN.+ | Right / Tun+ | ▶ | Right |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| TUN.+ | Right / Tun+ | SHIFT + TUNE+ | Shift + >> / | 9 | 9 | BLUETOOTH 9 | 9 |
| PRESET – | Down / Preset- | ▼ | Down | 0 | 0 | HDMI - SAT 0 | 0 |
| PRESET – | Down / Preset- | SHIFT + PRESET- | Shift + I<< / Preset- | RDS/RESOL | RDS | RDS AV INPUT | AV / Input / RDS |
| VSM | VSM | CH PAGE + | CH+ / Page+ | TV POWER | TV Power | SHIFT + ⏻ | Shift + Power |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear | CHANNEL + | TV PR + | SHIFT + CH PAGE + | Shift + CH+ / |
| VOL + | Vol + | VOL + | Vol + | VOLUME + | TV Vol + | SHIFT + VOL + | Shift + Vol + |
| XTS Pro | XTS Pro | CH PAGE – | CH- / Page- | INPUT | TV Input | SHIFT + RDS AV INPUT | Shift + AV / Input / RDS |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer | CHANNEL – | TV PR - | SHIFT + CH PAGE – | Shift + CH- / |
| VOL – | Vol - | VOL – | Vol - | VOLUME – | TV Vol - | SHIFT + VOL – | Shift + Vol - |
| 1 | 1 | TV 1 | 1 | | | | |
| 2 | 2 | DVD 2 | 2 | | | | |
| 3 | 3 | CD - STB 3 | 3 | | | | |
| 4 | 4 | VIDEO 4 | 4 | | | | |
| 5 | 5 | TAPE 5 | 5 | | | | |
| 6 | 6 | TUNER 6 | 6 | | | | |
| 7 | 7 | AUX - HDD 7 | 7 | | | | |
| 8 | 8 | USB 8 | 8 | | | | |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 | ▶ | Play | SLOW ▶ | Play / Slow |
| POWER | Power | POWER | Power | ⏸ | Pause | STEP - FREEZE ⏸ | Pause / Step / Freeze |
| EJECT | Eject | SURROUND ⏏ | Eject / Surround | PROG./CLEAR | Prog / Memo | PROGRAM TV/RADIO | TV/Radio / |
| USB | USB | SHIFT + USB 8 | Shift + 8 | ◀◀ | << | TUNE- ◀◀ | << / Tune- |
| DISC | DVD | SHIFT + DVD 2 | Shift + 2 | ⏮ | I<< | PRESET- ⏮ | I<< / Preset- |
| MOBILE | Aux | SHIFT + AUX - HDD 7 | Shift + 7 | ⏭ | >>I | PRESET+ ⏭ | >>I / Preset+ |
| DIMMER | Dimmer | SHIFT + DIMMER MUTE | Shift + Mute / Dimmer | ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer | MENU/LIST | Menu | HOME MENU | Menu / Home |
| REPEAT | Repeat | APP REPEAT | Green / APP / Repeat | SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| A-B | A-B | YouTube REPEAT A-B | Yellow / YouTube / Repeat | DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| MARKER | Marker | PC FAV MARKER | Fav / Marker / PC | PRESET + | Up / Preset + | ▲ | Up |
| SEARCH | Search | NETFLIX SEARCH | Red / Netflix / Search | RETURN | Return | RETURN BACK | Back / Return |
| TITLE | Title | SHIFT + TITLE SOUND | Shift + Sound / Title | TUN.– | Left / Tun. - | ◀ | Left |
| ZOOM | Zoom | SIZE ZOOM | Zoom / Size | ENTER | Enter | OK | OK |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II | TUN.+ | Right / Tun. - | ▶ | Right |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ | PRESET – | Down / Preset | ▼ | Down |
| ■ | Stop | HOLD ■ | Stop / Hold | VSM | VSM | LIST SMART | Smart / List |

| Original | | Replacement | |
|---|---|---|---|
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| + VOL | Vol + | + VOL | Vol + |
| XTS Pro | XTS Pro | GOTO TEXT | Text / Goto |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| VOL – | Vol - | VOL – | Vol - |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| RDS/RESOL | RDS / Resol. | ANGLE INFO | Info / Angle |
| TV POWER | TV Power | SHIFT + | Shift + Power |

| Original | | Replacement | |
|---|---|---|---|
| + CHANNEL | TV PR + | + CH PAGE | CH+ / Page+ |
| + VOLUME | TV Vol + | SHIFT + + VOL | Shift + Vol + |
| INPUT | TV Input | RDS AV INPUT | AV / Input / RDS |
| CHANNEL – | TV PR - | CH PAGE – | CH- / Page- |
| VOLUME – | TV Vol - | SHIFT + VOL – | Shift + Vol - |
| | Sound | TITLE SOUND | Sound / Title |
| | PTY / HDM | FORMAT PICTURE | Picture / Format |