Mandis shop

REMCON2079

Original	Replacement	Original	Replacement
A1	1		
A2	2		
Stop	Stop / Hold		
Folder up	Up		
I<</ Back	I<< / Preset-		
>>I / Next	>>I / Preset+		
Folder down	Down		
Prog	TV/ Radio /		
Play (CD/USB)	Play / Slow		
Pause (CD/USB)	Pause / Step / Freeze		
Mode	Picture / Format		

https://mandis.com/en/itsimagical/1668-958-replacement-remote-control-for-itsimagical-REMCON2079.html