Mandis shop

Hisense EN205A7H

Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
MOVIE	Movie	PROGRAM TV/ RADIO	TV/Radio /
MUSIC	Music	LANG I/II AUDIO	Audio / Lang I/II
VOL+	Vol+	VOL+	Vol+
VOL+	Vol+		Up
	I<	PRESET-	I<< / Preset-
	I<		Left
▶II/PAIR	Play	SLOW ▶	Play / Slow
▶II/PAIR	Pause	STEP - FREEZE II	Pause / Step / Freeze
▶II/PAIR	Pair	OK	OK
	>I	PRESET+	>>I / Preset+
	>I		Right
VOL–	Vol-	VOL–	Vol-
VOL–	Vol-		Down
NEWS	News	ANGLE INFO	Info / Angle
HDMI ARC	HDMI ARC	HDMI - SAT 0	0

Original		Replacement	
OPT COAX	OPT Coax	OPT-TOOLS SETUP	Setup / OPT /
	Bluetooth	BLUETOOTH 9	9
LINE IN	Line In	CD - STB 3	3
USB	USB	USB 8	8

https://mandisremotes.com/en/Hisense/1066905-96374-replacement-remote-control-for-Hisense-EN205A7H-WT0039938.html