Mandis shop

Original	Replacement	Original	Replacement
Power	Power	Down	Down
1	1	Back	Back / Return
2	2	Voice	Sound / Title
3	3	+	Fav / Marker / PC
4	4	Vol +	Vol +
5	5	Mute	Mute / Dimmer
6	6	P+	CH+ / Page+
7	7	Vol -	Vol -
8	8	P-	CH- / Page-
9	9	<<	<< / Tune-
0	0	Play/Pause	Pause / Step / Freeze
Guía	Guide / EPG / -/--	Play/Pause	Play / Slow
Menu	Menu / Home	>>	>> / Tune+
Up	Up	I<	I<< / Preset-
Left	Left	Stop	Stop / Hold
OK	OK	Rec	Rec / Rec Mode
Right	Right		

https://mandisremotes.com/en/Movistar/10675-89538-replacement-remote-control-for-Movistar-74896.html