Original		Replacement		Original		Replacement	
POWER	Power		Power		Left		Left
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	OK	OK	OK	OK
TV/RADIO	Play	SLOW	Play / Slow		Right		Right
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze	EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
RECORD	Record	REC MODE	Rec / Rec Mode	CH-	Down		Down
ALT	<</ Alt	TUNE-	<< / Tune-		Vol +	VOL +	Vol +
LIST	>>/ List	TUNE+	>> / Tune+	A-SCAN /A-TIME	A-Scan/ A-Time	LIST SMART	Smart / List
RECORD	I <<	PRESET-	I << / Preset-	CH+	CH+	CH PAGE +	CH+ / Page+
TEXT	>>I	PRESET+	>>I / Preset+		Vol -	VOL −	Vol -
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II	CH-	CH-	CH PAGE −	CH- / Page-
SUB	SUB	EQ SUBTITLE	Subtitle / EQ	1	1	TV 1	1
ZOOM	Zoom	SIZE ZOOM	Zoom / Size	2	2	DVD 2	2
TV/RADIO	Tv/ Radio	PROGRAM TV/ RADIO	TV/ Radio /	3	3	CD - STB 3	3
TEXT	Text	GOTO TEXT	Text / Goto	4	4	VIDEO 4	4
MENU	Menu	HOME MENU	Menu / Home	5	5	TAPE 5	5
CH+	Up		Up	6	6	TUNER 6	6
INFO	Info	ANGLE INFO	Info / Angle	7	7	AUX - HDD 7	7

Original		Replacement		Original	Replacement
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
FAV	FAV	PC FAV MARKER	Fav / Marker / PC		
RECORD	Red	NETFLIX SEARCH	Red / Netflix / Search		
AUDIO	Green	APP REPEAT	Green / APP / Repeat		
PAUSE	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
TEXT	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
USB/ MOVE	USB/Move	SHIFT + USB 8	Shift + 8		