Mandis shop

Philips 996510023877

Original	Replacement
Power	Power
Mute	Mute / Dimmer
I<<	I<< / Preset-
>>I	>>I / Preset+
Sound	Sound / Title
Source Audio	Audio / Lang I/II
Surround	Eject / Surround
Sleep	Sleep / Timer
Radio	TV/Radio /
Source/HDMI	AV / Input / RDS
Audio	Menu / Home
Up	Up
Double Bass	Info / Angle
Left	Left
OK	OK
Right	Right
Delete	Exit / Cancel / Clear

Original	Replacement
Down	Down
Back	Back / Return
Vol +	Vol +
Vol -	Vol -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0