Original	Replacement	Original	Replacement
On/Standby	Power	Return	BACK
Display	INFO	Title	OPT+
Open/Close	P/C / FAV	OK	OK
1	1	Up	UP
2	2	Down	DOWN
3	3	Right	RIGHT
4	4	Left	LEFT
5	5	<<	Rewind
6	6	>>	Fast Forward
7	7	I <<	First
8	8	>>I	Last
9	9	Play/Pause	Play
0	0	Step	Pause
+10	-/-- / EPG	Stop	Stop
T-Search	SRC	Repeat	TEXT
Menu	MENU	A-B	TV/R
Setup	VOD	Clear	EXIT

Original		Replacement		Original	Replacement
SUBTITLE	Subtitle		Subt.		
AUDIO	Audio		Audio		
SLOW	Slow	V-FOR	V-FOR		
ZOOM	Zoom	WIDE	WIDE		
PROG	Prog	MEDIA	MEDIA		
RANDOM	Random	B	Green (B)		
ANGLE	Angle	A	Red (A)		