Original		Replacement	
POWER	Power		Power
MUTE	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	SHIFT + -/-- GUIDE	Shift + Guide
	Recall	RETURN BACK	Back
AUDIO	Audio	SOUND DUAL	Dual
FAV	FAV	FAV PRE-CH	Pre Ch
FAV+	FAV+	SHIFT + CH +	Shift + Ch +

Original		Replacement	
FAV-	FAV-	SHIFT + CH −	Shift + Ch -
P.MODE	P.Mode	APP MEDIA	Media
S.MODE	S.Mode	SETTINGS OPT	Options
CH +	CH+	CH +	Ch +
CH −	CH-	CH −	Ch -
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
INPUT	Input	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
ASPECT	Aspect	ECO 3D	3D
INFO	Info	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement	
OK	OK	OK	Ok
TEXT	Text	REPEAT TEXT	Text
INDEX	Index	HOME SMART	Smart
MIX/T	Play/Mix/T	PLAY MODE ▶	Play
MIX/T	Pause	❚❚	Pause
REVEAL	Stop/Reveal	■	Stop
HOLD	<<</Hold	<<	<<
SUBPAGE	>>/Subpage	>>	>>
SIZE	I<<	I<<	I<<
CANCEL	>>I/Cancel	>>I	>>I
REC	Rec	REC MODE	Rec
SIZE	Size	PICTURE FORMAT	Format
EPG	EPG	-/-- GUIDE	Guide
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R
SUB-T	Sub-T	AD SUBT	Subt
	Red	A	Red
	Green	B	Green

Original		Replacement	
	Yellow	C	Yellow
	Blue	D	Blue