| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Last | Back |
| Mute | Mute | Menu | Menu |
| TV / R | TV/R | Exit | Exit |
| Mode | Smart | Up | Up |
| EPG | Guide | Ch + | Ch + |
| Text | Text | Down | Down |
| 1 | 1 | Ch - | Ch - |
| 2 | 2 | Right | Right |
| 3 | 3 | Vol + | Vol + |
| 4 | 4 | Left | Left |
| 5 | 5 | Vol - | Vol - |
| 6 | 6 | OK | Ok |
| 7 | 7 | Info | Info |
| 8 | 8 | Sub-T | Subt |
| 9 | 9 | PVR | AV |
| 0 | 0 | Audio | Dual |
| Favor | Pre Ch | I> | >>I |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | Red | | Red | | |
| | << | | << | | |
| | Green | | Green | | |
| | >> | | >> | | |
| | Yellow | | Yellow | | |
| | Play | | Play | | |
| | Pause | | Pause | | |
| | Blue | | Blue | | |
| | Stop | | Stop | | |
| | Rec | | Rec | | |