| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| DIMMER | Dimmer | SETTINGS OPT | Options |
| CLOCK | Clock | TIMER AV | AV |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| CD | CD | A | Red |
| TUNER | TUNER | B | Green |
| iPod/USB | iPod/USB | C | Yellow |
| OPTICAL IN 2 | Optical In 2 | APP MEDIA | Media |
| OPTICAL IN 1 | Optical In 1 | D | Blue |
| ANALOG IN | Analog In | SOUND DUAL | Dual |
| ⏮ | I<< | K< | I<< |
| ▶/II | Play | PLAY MODE ▶ | Play |
| ▶/II | Pause | II | Pause |
| ⏭ | >>I | >>I | >>I |
| TUNE – ◀◀ | <<Tune- | << | << |
| ■ | Stop | ■ | Stop |
| TUNE + ▶▶ | >>Tune+ | >> | >> |

| Original | | Replacement | |
|---|---|---|---|
| CHANNEL + | CH+ | + CH | Ch + |
| CHANNEL – | CH- | CH – | Ch - |
| MUTE | Mute | MUTE | Mute |
| VOLUME ▲ | Vol + | + VOL | Vol + |
| VOLUME ▼ | Vol - | VOL – | Vol - |
| SDB TONE | SDB Tone | AD SUBT | Subt |
| FOLDER/ALL | Folder/All | DISC NAV LIST | List |
| INFO | Info | DISPLAY INFO | Info |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |
| ▶ | Right | ▶ | Right |
| ◀ | Left | ◀ | Left |
| ENTER | Enter | OK | Ok |
| DAB/RDS | DAB/RDS | PICTURE FORMAT | Format |
| 1 | 1 | 1 | 1 |
| SETUP | Setup | TOP MENU MENU | Menu |
| 2 | 2 | 2 | 2 |

| Original | | Replacement | |
|---|---|---|---|
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| +10 | + 10 | -/-- GUIDE | Gui de |
| CLEAR | Cl ear | CLEAR EXIT | Exi t |
| RANDOM | Random | SEARCH TV/R | TV/ R |
| REPEAT | Repeat | REPEAT TEXT | Text |
| PROGRAM | Pr ogr am | SHIFT + PROG SLEEP | Shi f t + Sl eep |
| MODE | Mode | ECO 3D | 3D |
| | | | |
| | | | |
| | | | |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |